

[Strona główna](#) » [Dual](#) » Dual CS 429 W pełni automatyczny gramofon Hi-Fi
Instrukcja obsługi 

Dual

Podstawy informatyki 429



Instrukcja obsługi: Gramofon Hi-Fi w pełni automatyczny


zawartość


- 1 Specyfikacje techniczne**
- 2 Wstęp**
- 3 Instrukcje bezpieczeństwa**
- 4 Spis treści / Instrukcje pakowania**
- 5 Przegląd produktu**
- 6. Konfiguracja**
- 7 Obsługa gramofonu**
- 8 Czyszczenie i rozwiązywanie problemów**
- 9 Dokumenty / Zasoby**
 - 9.1 Odniesienia**
- 10 Powiązanych Postów**



Dane techniczne

Dane techniczne	
Silnik	
Prowadzić	Silnik pasowy/prądu stałego sterowany serwo-mechanizmem z optyczną kontrolą prędkości
Ustawienia prędkości	33/45/78
Wow i trzepotanie	< ±0,08 % (DIN WTD)
Ramię gramofonu	
Funkcjonować	Wszystkie funkcje mogą być w pełni automatyczne lub ręczne
Łożysko	Łożysko kulkowe
Efektywna długość	221,5 mm
 Kąt przesunięcia	25,6°
Zwis	19 mm
Typ	wyważony statycznie z przeciwwagą

Zakres nacisku igły	0 do 4 gramów
Zakres wagi wkładu	5g do 9g
Pick-up zainstalowany fabrycznie	Ortofon 2M Czerwony
Zamienny rysik	Rysik Ortofon 2M czerwony
Talerz	
Tworzywo	Odlew aluminiowy
Mata	Guma 2,5mm
Łożysko	Hartowana stalowa wrzeciono, tuleja mosiężna
Średnica	305 mm
Waga z matą	850 gramów
Cokół	
 Wykończenie powierzchni	Składana konstrukcja z płyty MDF z czarną okleiną winylową
Stopy	Ø 62 mm / Element tłumiący z elastomeru

Połączenie	Gniazdo RCA
Podłączenie do wejścia Phono	TAK
Podłączenie do wejścia liniowego	TAK
Wyjście cyfrowe	X
Wymiar (zamknięta osłona przeciwpyłowa)	Wymiary: 435 x 367 x 145 mm
Wymiar (otwarta osłona przeciwpyłowa)	Głębokość: 415 mm / Wysokość: 400 mm
Waga	6,2 kg
Zasilacz	Odczyty wydajności wykonywano przy napięciu wejściowym
	230 V AC przy 50 Hz
Typ	HK-CW-120A200-CP
 Napięcie wejściowe	100 (-10 %) V AC do 240 (+10 %) V AC
Częstotliwość	50/60 Hz
Napięcie wyjściowe	12 V prądu stałego

Prąd wyjściowy	2,0 A
Moc wyjściowa	24 W
Średnia wydajność podczas pracy	≥ 86,2% przy średniej 25/50/75/100% obciążeń wejściowych 115 i 230 VAC
Pobór mocy w stanie spoczynku	< 0,1 W

Przedmowa

Niniejsza instrukcja obsługi pomoże Ci bezpiecznie obsługiwać gramofon. Przed użyciem urządzenia przeczytaj uważnie tę instrukcję i uwagi dotyczące bezpieczeństwa oraz zachowaj je do późniejszego wykorzystania. Upewnij się, że są dostępne dla innych użytkowników i przestrzegaj wszystkich podanych tutaj informacji.

Przeznaczenie niniejszej instrukcji obsługi


Niniejsza instrukcja obsługi jest przeznaczona dla wszystkich osób, które:

- ustawia,
- działa,
- czyści
- lub pozbywa się gramofonu.

Ostrzeżenia

🌀 Znaki ostrzegawcze w niniejszej instrukcji obsługi są ustrukturyzowane w sposób pokazany poniżej:

 **Danger** Słowo „NIEBEZPIECZEŃSTWO” wskazuje na bezpośrednie zagrożenie życia!

 **Warning** Słowo „OSTRZEŻENIE” wskazuje na potencjalną sytuację zagrażającą życiu lub nieodwracalne obrażenia!

 **Careful** Słowo „OSTROŻNIE” wskazuje na możliwe zagrożenie średnimi lub lekkimi

obrażeniami!

ATTENTION

Słowo „UWAGA” wskazuje na potencjalne uszkodzenia produktu.

Note:

„NOTE“ provides useful or important information.

Directives and standards



This product conforms to:

- the Low-voltage Directive (2014/35/EU),
- the EMC Directive (2014/30/EU),
- RoHS Directive 2011/65/EU,
- ERP 2009/125/EC and
- CE Marking Directive.

Disposal of packaging



„Danger“ through suffocation!

Keep the packaging and its parts out of the reach of children. Risk of suffocation from foil and other packaging materials. Your new unit was protected on its way to you by the packaging. All materials used are environmentally safe and can be recycled. Please help and dispose of the packaging in an environmentally responsible manner. To learn about current disposal methods, contact your dealer or your local disposal facility.



Disposal of turntable

Old units are not simply waste. Valuable raw materials can be salvaged through environmentally friendly disposal. For information about the correct and environmentally friendly disposal of your unit, please contact your local council. This unit is labelled according to 2002/96/EC, the Waste Electrical and Electronic Equipment Directive (WEEE). This product must not be disposed of with normal household waste. Instead, it must be deposited at a recycling station for electrical and electronic devices. The symbol on the product and the instructions for use or the packaging indicate this. The materials can be recycled in accordance with their marking. By re-using, recycling, or repurposing old units, you make an important contribution to protecting our environment.

Safety instructions

Please read through all of the safety instructions carefully and keep them for questions that may arise later. Always observe all warnings and instructions in this operating manual and on the rear

of the unit.



Safety instructions for using the power supply

- The unit should only be connected to a mains voltage supply of 100- 240 V~, 50/60 Hz.
- Never try to operate the unit with a different voltage.
- Only use the supplied power supply or an original Dual alternative.
- The mains plug should only be connected after installation has been completed according to the instructions.
- Use a suitable, easily accessible mains connection and avoid using multiple sockets!
- This socket should be as close to the unit as possible.
- Make sure the power cable or plug is always easily accessible so that the unit can be disconnected quickly from the power supply!
- Lay the mains cable in such a way that no one can trip over it and do not place any heavy objects on the mains cable.
- Fully insert the mains plug into the socket.
- Do not touch the mains plug with wet hands—risk of electric shock!
- If the mains plug of the unit is defective or if the unit shows other damage, it must not be operated.
- When unplugging the mains cable from the socket pull on the mains plug, not on the cable.
- Disconnect the mains plug from the socket if you do not intend to use the unit for a prolonged period. Only pull on the plug itself.
- In the event of malfunctions or smoke and odour coming from the housing disconnect the mains plug from the socket immediately!
- Before a thunderstorm sets in, disconnect the mains plug from the socket.



Safety instructions for the turntable placement

- In order to avoid the risk of fire and electric shock, do not expose the unit to rain or moisture.
- Prevent the unit from coming into contact with water or moisture.
- The appliance should not be sited in rooms with high levels of humidity, e.g. kitchens, bathrooms or saunas, or in the vicinity of swimming pools indoors or outdoors, as splashing or the formation of condensation on the appliance may damage it.

- Do not place any containers which contain a liquid on the unit, such as a flower vase. These could fall over and the spilled liquid could lead to severe damage to the unit or the risk of electric shock or fire.
- No open flames, such as burning candles, are permitted to sit on the unit.
- Foreign material, e.g. needles, coins, etc., should not be allowed to enter the unit.
- If any foreign material or liquid enters the unit, disconnect the plug from the socket immediately. Get the unit checked by a specialist before starting to use it again. Failure to do this will leave you at risk of receiving an electric shock!

ATTENTION

Safety instructions for repairs and servicing

- Never attempt to repair a defective unit yourself. Always contact one of our authorised customer service representatives.
- Always leave maintenance to a qualified technician. Failure to do this will put you and others in danger.
- Never open the unit under any circumstances – this should only be undertaken by a specialist.
- Do not open the housing. Doing so will put you at risk of receiving an electric shock!
- Making modifications to the appliance is prohibited.
- Do not continue to use the appliance and/or accessories if they are damaged.
- Use only appropriate cleaning agents (antistatic) to clean the unit and the records. These are available from your specialist retailer.



CAUTION

DO NOT OPEN

RISK OF ELECTRIC SHOCK



Careful

Safety instruction for operating the turntable

- Do not listen to music or radio broadcasts at very high volumes. Doing so can cause lasting damage to your hearing.
- This appliance should only be operated by a competent owner or persons under direct supervision of the owner or who are deemed by the owner to be competent to do so.

Intended use and application

The appliance is intended for playing vinyl records. The appliance is designed for use in a private home and is not suitable for commercial use. Use of any other kind is classed as other than

intended and may result in damage to property or even personal injury. The manufacturer accepts no liability whatsoever for loss or damage arising from use of the appliance in a manner other than that intended. Before using the appliance for the first time, please read through the safety and installation instructions carefully. Only by doing so will you be able to use all functions safely and reliably. Keep the installation instructions in a safe place and pass them on to any subsequent owner.

List of contents / Packing instructions


Unpacking

1. First, remove the appliance and all associated parts from the packaging.
2. Remove all adhesive tapes.
3. Ensure that all listed components are present:

Note:

- The small components are in the side compartments of the polystyrene packaging sections!
- Do not throw the stylus guard for the needle away!
- Retain the packaging for any possible future transportation!

List of contents

- Record player,
- 2 hinges for the dust cover,
- Dust cover,
- Headshell with phono cartridge,
- Platter including belt,
- Platter mat,
- Counterweight,
-  Spindle adaptor (for 7" EPs),
- Power supply for connecting to the main supply,
- Coaxial stereo audio cable.

Note:

If any of these elements are missing, please contact the supplier.

Repacking


1. Repack all component parts in the corresponding, original packaging.
2. The counterweight must be dismantled and stowed in one of the polystyrene sections (fixed securely with sticky tape)
3. Remove the turntable. (Never transport the record player with the platter in position)
4. Secure the stylus with the protective cover for the needle and remove headshell.
5. Attach the tonearm securely to the tonearm rest.
6. Ensure that none of the small parts or associated packaging can move inside the cardboard box.

Note:

For further information, please go to www.dual.de



Product overview



Nr	Description	
1	Dust cover hinges (2×)	
2	Platter	
3	Platter mat	
4	Platter bearing	
5	PHONO / LINE Switch	Phono-preamp on-/off
6	RCA-Audio-Output R / L	red – right channel, white – left channel
7	GND: Ground connection	
8	Power switch	ON / OFF
9	DC IN: 12 V-Input for Power supply	
10	Start / Stop buttons	
11	Speed selector	33, 45, 78

12	Tonearm	
13	Counterweight	
14	Tracking force dial	
15	Tonearm lift	
16	Tonearm rest with safety fastener	
17	Anti-Skating-Adjustment	
18	Tonearm lift lever	
19	Lever record size	17, 30
20	Tonearm	
21	Union nut	
22	Headshell	


Set Up

Platter and belt installation

The record player is delivered with the drive belt already fitted around the turntable flange. The belt is provided with a red tape so that it can be pulled over the drive motor pulley. (pic. 1)

1. Place the turntable on the turntable spindle. Rotate the turntable until the cut-out is positioned over the motor pulley (at about the 8 o'clock position).
2. Using the red tape, pull the drive belt over the motor drive pulley and position it in the centre of the pulley. Then remove the red tape.
3. Now place the turntable mat on the turntable.






Pic. 1

Tonearm

The tonearm is secured at the tonearm rest with a coated wire and the safety clip. Remove and discard the coated wire and open the safety clip to play the record.




Pic. 2

Fitting the headshell

Fit the removable headshell onto the tonearm as described below: (pic. 2)

1. Place the headshell (1) into the socket (2) at the end of the tonearm (3).
2. Hold the headshell, while turning the socket (2) in the direction of the arrow.





Pic. 3

Balancing the tonearm

ATTENTION

Damage to the stylus

Ensure that the stylus does not come in contact with the platter mat, or any other part of the turntable.

1. Place the turntable on an even horizontal surface.
2. Remove the stylus guard (page 20).
3. Lower the tonearm lift via the tonearm lift lever.
4. Position the tonearm in between the platter and the tonearm rest. (not resting on the stylus)
5. Turn the anti-skating dial (3) to „0” (pic. 3).
6. Turn the counterweight (2) backwards or forwards until the tonearm reaches a horizontal balance.
7. Place the balanced tonearm back onto the tonearm rest and secure it with the clip.
8. (Pic 4) Hold the counterweight (1) in position while turning the tracking force dial (2) to „0” (12 o'clock position).


Tracking force

The tracking force needs to be adjusted according to the installed pick-up. (pic. 4)

1. Adjust the entire counterweight (1) including the scale to the required weight (2).
2. The tracking force weight can be read from the scale.

Note:

The recommended force / weight for the supplied pick up is between 1,6 g and 2,0 g. If in doubt, please consult the pick-up manufacturer for recommended values.




Pic. 4

Anti-Skating-adjustment

The skating force pulls the tonearm towards the centre of the platter. This increases the pressure on the inside wall of the groove. The ANTI-Skating force compensates this movement and ensures the ideal tracking of the stereo information on the vinyl.


- Set the Anti-skating dial (1) to the same value setting as the tracking force. (pic. 5)



Pic. 5

Dust cover fitting

1. Slot both hinges (2) into the housings (3) in the back of the turntable.
2. Uniformly push the right and left dust cover (1) receptacles onto the hinges



Connection to Amplifier

The turntable comes with a built-in phono pre-amplifier. It can be either connected to the phono input or the line input at the amplifier.

The built-in phono stage can be switched on or off via a switch in the back of the turntable.


Phono-Input

1. Connect the RCA cable to the Audio output „AUDIO OUT” (2) at the turntable and the PHONO input sockets at the amplifier.
2. Move the switch (1) into the position: PHONO.
3. Connect the ground connection GND (3) with the amplifier to avoid noise.

Note:

Ensure the correct connection of the cable.
(red = right channel, white = left channel)






Line-Input

1. Connect the RCA cable to the Audio output „AUDIO OUT” (2) at the turntable and the LINE / AUX input sockets at the amplifier.
2. Move the switch (1) into the position: LINE.
3. Connect the ground connection GND (3) with the amplifier to avoid noise.

Note:

Ensure the correct connection of the cable.
(red = right channel, white = left channel)





Connection to Power Supply


Different adapter plugs (1) are included with the product. Find the specific adapter relevant to your country and socket system. Fit it to the power supply (2).

1. Fit the socket adapter into the power supply and twist in the direction of the arrow (A).
2. Check that the adapter is locked correctly (B).
3. Plug the power supply into a power socket (C).

Note:


Only use a factory supplied or approved power supply.





Damage to the turntable!

Incorrect voltages can damage the product. Ensure that the mains voltage is within the stated specification.




Operating the turntable


Removing / Attaching the stylus protection cap

Remove the stylus protection cap from the pick-up (1) prior to playing a record. (Pic.1)

1. Push the stylus cap (2) on the bottom (B) as seen in the diagram. Hold in position (A) while move it up in circular motion (C).
2. Replace the cap after playing the record.




To play the record (manually)



1. Push the power button (8). The LEDs for  and “33” will turn on.
2. Place a record on the turntable; use the spindle adaptor to play singles.
3. Turn the speed selector (11) to the required setting: 33, 45 or 78. The selected speed will be indicated via the LED.
4. Release the safety fastener on the tonearm rest and raise the tonearm with the lift lever.
5. Carefully move the tonearm away from the tonearm rest and position it above the first groove on the record. The motor is turned on.
6. Lower the tonearm with the lift lever.
7. The tonearm will return to the tonearm rest automatically at the end of the record and the motor will switch off.
8. Secure the tonearm with the safety fastener on the tonearm rest.


Note:

-  The tonearm can be raised at any point, even for short periods. The platter will continue to turn.

To play the record (automatically) **Pic.2**

1. Push the power button (8). The LEDs for  and “33” will turn on.
2. Place a record on the turntable, use the spindle adaptor to play singles and select the record size (19).

3. Turn the speed selector (11) to the required setting: 33, 45 or 78. The selected speed will be indicated via the LED.
4. Release the safety fastener on the tonearm rest and press the start button (1).
5. The platter will start turning and the arm will move towards the first groove and will be lowered onto the record. The  LED will flash during the operation.
6. The operation can be stopped at any time with the STOP button (2). The tonearm will return to the tonearm rest automatically. The  LED will flash.
7. The tonearm will return to the tonearm rest automatically at the end of the record and the motor will switch off.
8. Secure the tonearm with the safety fastener on the tonearm rest.



Pic. 2

To set the speed

The exact speed is fixed through an internal processor. There is no further adjustment.

Replacing the stylus


The stylus is naturally exposed to wear and tear by the playback process. Therefore, we recommend regular inspections.

1. Remove the stylus by pulling diagonally downwards. (Pic. 3)
2. Insert the stylus by doing the performing the reverse action.

Note:

Worn or damaged (splintered) styluses ruin records.

When you need to replace a stylus, use the original type if possible.



Pic. 3

Cleaning & Troubleshooting

Cleaning stylus and record

Clean the stylus and record prior to every record played. That minimises premature wear and tear.

ATTENTION

Damage to components!

1. Carefully wipe the stylus brush in a front to back motion under the stylus.
2. To clean a record, use a carbon fibre brush to wipe gently and diagonally over the record.

Note:

Brushes and accessories are available in the Dual shop: www.dual.eu

Cleaning the record player



Warning



Danger – Electric shock!

To avoid the danger of an electric shock, you must not clean the unit with a wet cloth or under running water.

Pull the power plug prior to any cleaning.

ATTENTION

Damage to components!

Do not use any scrubbing sponges, cleaning powder or solvents such as alcohol and petrol. To clean the appliance and the records, only use cleaning agents that are specifically designed for the purpose (antistatic).

Troubleshooting

If the unit does not function as intended, perform checks using the following tables.
If the malfunction cannot be fixed even after these checks, please contact the manufacturer.

Symptom – Possible causes	Solutions
The tone arm skips grooves, slides over the record or does not move.	<ul style="list-style-type: none">• The record player is not sitting horizontally. Place the record player on a horizontal base support.• The record is dirty or scratched. Clean the record with a record cleaner or change the record.• The stylus pressure of the tone arm may be too low. Adjust the stylus pressure and check the anti-skating setting.
Poor sound quality, loud static noise, sound dropouts, etc.	<ul style="list-style-type: none">• The stylus is dirty or worn. Clean the stylus with a brush.• The stylus may be defective. If necessary, change the stylus.• The record is dirty or dusty. Clean the record with a record cleaner.
The sound is too quiet or loud and distorted.	<ul style="list-style-type: none">• The record player is not connected to the correct amplifier input.• The internal phono pre-amp is set to the wrong setting. Change the switch setting in the back of the turntable.• Consult the manual setting: Set up – Connection to amplifier


Spare parts & Accessories

Spare parts and accessories are available from Dual: www.dual.eu

Dual

Hersteller

DUAL GmbH · Graf-Zeppelin-Str. 7 · D-86899 Landsberg
www.dual.eu · E-Mail: support@dual.de



[Dual CS 429 W pełni automatyczny gramofon Hi-Fi \[pdf \]](#) Instrukcja obsługi CS 429 W pełni automatyczny gramofon Hi-Fi, CS 429, Gramofon CS 429, W pełni automatyczny gramofon Hi-Fi, Automatyczny gramofon Hi-Fi, Gramofon Hi-Fi, Automatyczny gramofon, Gramofon

Odniesienia

- [Instrukcja obsługi](#)

[Manuals+](#) | [Prześlij](#) | [Głębokie wyszukiwanie](#) | [Polityka prywatności](#) | [@manuals.plus](#) | [YouTube](#)

Ta strona internetowa jest niezależną publikacją i nie jest ani powiązana, ani popierana przez żadnego z właścicieli znaków towarowych. Znak słowny „Bluetooth®” i logo są zarejestrowanymi znakami towarowymi należącymi do Bluetooth SIG, Inc. Znak słowny „Wi-Fi®” i logo są zarejestrowanymi znakami towarowymi należącymi do Wi-Fi Alliance. Jakiegokolwiek użycie tych znaków na tej stronie internetowej nie oznacza żadnego powiązania ani poparcia.

