

HAIR STRAIGHTENER

Thank you for choosing our product.

Before using the product, please read below information and manual instruction carefully and keep it for future reference.

IMPORTANT SAFETY INFORMATION AND PROPER USE OF THE DEVICE

1. During warranty period is recommended to keep the original packaging and proof of purchase, which is also a guarantee card in case of complaints. During transport, the device must be placed in its original packaging;
2. Before first use, remove the packing and remove everything from inside;
3. Do not reach for the device if it fell into the water, immediately disconnect it from the power supply;
4. Never use the appliance near a bathtub, shower or swimming pool;
5. Do not store the device in a place where it can come into contact with water;
6. The device must be disconnected from the power supply immediately after use;
7. When cleaning the unit must be disconnected from power supply;
8. The device cannot be left unattended during operating;
9. Children and persons with reduced physical or mental efficiency can use the device under the control of the people that will guarantee their safety;
10. The device and its wire must be kept out of the reach of children under 8 years of age. The device is not a toy;
11. Do not use the device for purposes other than those for which it is intended;
12. Before connecting the plug into an electrical socket, make sure that the voltage shown on the rating plate corresponds to the mains voltage in socket. If the voltages do not match, do not connect the device;
13. Never use accessories that have not been supplied with the device and are not recommended by the manufacturer;
14. Unplug the device by holding the plug, do not pull on the electric wire;
15. Do not use the device if the power cord or plug is damaged, exchange or repair should be entrusted to a specialized service. Individual interventions in the device during the warranty period will cause loss of this warranty.
16. Do not store or place the device, its accessories and cord near hot surfaces;
17. Do not spray aerosols in the vicinity of the device;
18. This appliance is intended for household use only, do not use it in an industrial environment or outside;
19. Keep in a dry, cool place (0-40° C), avoid exposure to sunlight;
20. Do not place the working device on metal surfaces and window sills;
21. Do not touch the working device with wet hands;
22. Do not use the device on open wounds, cuts, sunburns or blisters;
23. The manufacturer takes no responsibility for damages caused by incorrect use of the product and its accessories;
24. After use, leave the device to cool down;
25. Do not use the appliance on wet hair, wigs and hair of animals;
26. The device heats to a high temperature. Extreme care is needed during the operation.

DEVICE DESCRIPTION

This device is suitable for straightening dry hair. It is equipped as below:

1. Straightening ceramic plates;
2. ON/OFF switch;
3. LED indicator;
4. Power cord.

INSTRUCTION MANUAL

Before first use:

1. Remove the packing and remove everything from inside;
2. Plug the device into main supply;
3. Switch the device on by sliding the switch (2) to position ON;
4. Straighten the hair as described below.

USING THE DEVICE

1. Do not use on greasy, dirty, sweat hair. Before use they should be washed, dried and combed.
2. Use only on healthy hair. Permed and dyed hair should be straightened rarely.
3. Start the hair straightening from dividing the hair into equal strands.
4. Start from the back of the head and from the lower strands. Insert the strand of the hair between the plates and gently slide the straightener by pressing downward from the root to tip of the hair. Be careful do not touch the hot plates with hands or scalp.
5. Repeat step all over the head until you achieve the desired effect.
6. Do not use the straightener in one place longer than two seconds.
7. The speed of moving the hair straightener should be fitted to the character and quality of the hair. Thin hair needs shorter time of straightening than the thick hair.
8. Allow the hair to cool, then comb them.
9. Switch off the device by sliding switch (2) to the OFF position, then turn off from the power socket.
10. Allow to cool.
11. After each use, clean the device according to the instructions included in chapter "Cleaning and maintenance".

CLEANING AND MAINTENANCE

The ceramic plates need to be carefully cleaned after each use.

Before cleaning the device, turn it off and disconnect it from the electrical power socket.

1. To clean the outside parts of the device and ceramic plates use soft damp cloth with soap.
2. Do not use solvents, strong detergents and sharp objects, as they may damage the housing of the device.
3. Do not pour water or any other liquid on the device. Never immerse in water or any other liquid the lower part of the device connected to the power cord. Do not pour water or any other liquid into the device.

Technical data:

Voltage: 230 V;

Frequency: 50 Hz;

Power consumption: 22 W;

Max temperature: 170° C

GARANTIE

1. Garantie wird erteilt von der Firma EDC Poterek Sp. Jawna mit Sitz in: ul. Poznańska 129/133, 05-850 Ożarów Mazowiecki / POLEN, Tel. Servis: 022-7213571 Hausruf 10 – nachfolgend Esperanza genannt.
2. Dem Erwerber werden mit der vorliegenden Garantie Rechte und Berechtigungen der Esperanza gegenüber zuerkannt. Diese Garantie ist genau zu lesen, denn bei der Geltendmachung von Garantieansprüchen wird angenommen, dass der Verbraucher sich mit den Garantiebedingungen vertraut gemacht und diese akzeptiert hatte.
3. Esperanza versichert, dass jedes Produkt, inklusive der in der Verpackung enthaltenen Ausstattung, ist frei von Material- und Fabrikationsfehlern, vorausgesetzt es wird normal bestimmungsgemäß verwendet.
4. Tritt eine Beschädigung (Defekt) während der Garantiezeit auf, wird Esperanza nach eigenem Ermessen das gegebene Produkt reparieren oder gegen ein neues umtauschen, unter Anwendung von neuen oder fabrikmäßig erneuten Teilen. Im Fall der Anwendung von fabrikmäßig erneuten Teilen gewährleistet Esperanza, dass die Eigenschaften dieser Teile den neuen Produkten entsprechen werden.
5. Defektes Produkt sollte mit Empfang, Handelsrechnung oder einem anderen Kaufnachweis an den Ort des Kaufs zusammen zurückgegeben werden. Es sollte alles Zubehör in Originalverpackung befestigt ist. Esperanza hat Recht auf Garantie abzulehnen, wenn nicht alle Zubehör wird uns fehlen.
6. EDC Poterek Sp. Jawna deckt die Kosten für die Lieferung der beanstandeten Ware an den in der Garantie angegebenen Ort.
7. Esperanza ist verpflichtet, auf die Beschwerde innerhalb von 14 Kalendertagen nach der Mitteilung in der Verkaufsstelle zu reagieren. Esperanza wird das mangelhafte Produkt in kürzester Zeit zu reparieren. Wenn müssen aus dem Ausland importieren von Teilen, die notwendig sind, um die Reparatur dieses Mal kann verlängert werden.
8. Wenn EDC Poterek Sp. Jawna bei der Erfüllung seiner Aufgaben gewährt der berechtigten Person eine Garantie anstelle eines mangelfreien Gegenstandes oder führte wesentliche Reparaturen des von der Garantie abgedeckten Gegenstandes durch. Die Garantiefrist beginnt erneut mit dem Zeitpunkt der Lieferung des mangelfreien Gegenstandes oder der Rücksendung des reparierten Gegenstandes. Wenn EDC Poterek Sp. Jawna hat einen Teil der Dinge erwähnt, die vorstehende Bestimmung gilt entsprechend für den genannten Teil. In anderen Fällen verlängert sich die Gewährleistungsfrist um den Zeitraum, in dem der Gewährleistungsinhaber sie aufgrund eines Mangels an dem von der Garantie abgedeckten Gegenstand nicht nutzen konnte.
9. Muss ein Produkt gegen ein neues umgetauscht werden, hat Esperanza das Recht, dem Kunden ein neues Modell von ähnlichen Gebrauchseigenschaften zu geben, wenn es sich im Verkauf befindet und das alte Modell ersetzt hat.
10. Im Fall der Erhebung von Garantieansprüchen wird vorausgesetzt, dass der Erwerber seine Zustimmung geäußert hat, und dass die Reparatur und der Umtausch (je nach Verfügbarkeit des Produkts), je nach Entscheidung der Serviceabteilung, das einzige und das ausschließliche Mittel sind, Garantierechte gegenüber EDC Poterek Sp. Jawna geltend zu machen.
11. Die Garantie gilt in Polen.

GARANTIEAUSSCHLUSS:

Von der Garantie werden folgende Produkte nicht umfasst:

1. Produkte, die nicht von EDC Poterek Sp. Jawna hergestellt wurden
2. Produkte, die beschädigt wurden oder Fehler hatten infolge:
 - der Verwendung auf eine andere Art und Weise als ihre normale Bestimmung
 - der Modifikationen oder Ingerenzen in die innere Struktur des Gerätes
 - der Wartung bei nicht autorisierten Servicestellen oder bei einem anderen Service als der Service der Esperanza
 - der unangemessenen Aufbewahrung, des Transports oder des Packens
 - der falschen Installation der Produkte oder der Software
 - der mechanischen, physischen, chemischen Beschädigungen, u.ä.
3. Esperanza übernimmt keine Haftung für entstandene Schäden betreffend Geschäftsverlust, Verlust von Daten, Gewinnen oder für solche Schäden, die aus der Anwendung von Esperanza - Produkten in der Zusammenarbeit mit anderen Geräten resultieren.
4. Produkte mit zerstörten / beschädigten Siegeln, Aufklebern und Produkte, die hochgradig abgenutzt sind.

Auf alle EDC Poterek Sp. Jawna – Produkte wird eine Herstellergarantie von 2 Jahren erteilt.

Alle Produkte besitzen notwendige Sicherheitsbescheinigungen.



Gemäß der Richtlinie 2012/19/EU ist die Entsorgung von Elektro- und Elektronik-Altgeräten im Hausmüll untersagt. Die Bauteile unterliegen dem Recycling und sollen getrennt entsorgt werden. Anderenfalls können gefährliche und schädliche Stoffe freigesetzt werden und die Umwelt gefährden. Jeder Verbraucher ist dazu gesetzlich verpflichtet, die nicht mehr gebrauchte Elektro- und Elektronik-Altgeräte an die Hersteller, Verkäufer oder Sammelstellen kostenlos zurück zu geben. Die genauen Bedingungen werden durch die Vorschriften des jeweiligen Landes reguliert. Dieses Symbol auf Produkten oder deren Anleitung weist auf die Entsorgung hin. Dank der richtigen Mülltrennung sowie der Einhaltung von Vorschriften über das Recycling trägt jeder Verbraucher somit zum Umweltschutz bei.