



****Safety Warning:****

Before installing the XFX VGA, make sure to turn off your PC and unplug all cables. Ensure that the XFX VGA is correctly seated in the motherboard before powering on the PC.

Responsible entity in Europe:

Name: Distifor Lda

Address: Rua da Argila, 380 4445-027 Alfena
Portugal

Email: GPSR-EU@xfxforce.com

XFX

THE BEST GAMING GRAPHICS SINCE 2002

SERIES

AMD RADEON RX
AMD DESIGN SERIES

EDITION

QUICK GUIDE



English

System Requirements

1. Motherboard with PCI-E x16 compliant expansion slot.
2. Power supply with minimum recommended power requirements.
3. Supported Windows® or Linux based operating system.

Hardware Installation

1. Turn off the computer, monitor(s) and other peripheral devices.
2. Unplug the computer's power cord, and then disconnect all cables from the back of the computer.
3. Remove the cover to the computer's case.

NOTE: If necessary, consult the computer manual for help in removing the cover.

4. Remove any existing graphics card from the computer.
5. Locate the appropriate PCI-E x16 slot and, if necessary, remove the corresponding metal backplate cover(s). Make sure all internal cables are clear of the slot.
6. Align the graphics card with the slot and press it in firmly until the card is fully seated.
7. If your card requires supplementary power and must be connected directly to the power supply, locate the appropriate power connector cable(s) from the power supply and connect it (or them) to the graphics card's supplementary power connector(s). All power connections must be plugged in for the graphics card to operate.
8. Screw the graphics card securely to the back panel.
9. Make sure no internal cables are interfering with components inside the computer (for example, a cooling fan) and then replace the computer cover.
10. Reconnect any cables you have disconnected during installation, and then plug in the computer's power cord. Turn on the monitor, and then the computer.

AMD Radeon Software

1. **Important Note Before Starting.** The card must be physically installed before installing the driver and software. The driver will not install without the card being installed physically and driving a signal to your monitor.

NOTE: The first time you boot into windows, your card will be assigned a standard VGA graphics driver by windows. This is normal and allows the system to be used until the Radeon Driver is installed.

2. **Get the latest Driver.** Go straight to <http://support.amd.com> and download the latest driver for your graphics card. AMD releases driver updates on a regular basis, so it's highly recommended to get the driver direct.

Wymagania systemowe

1. Płyta główna z gniazdem rozszerzeń zgodnym z PCI-E x16.
2. Zasilacz o minimalnych wymaganiach mocy zalecanych przez producenta.
3. Obsługiwany system operacyjny oparty na Windows® lub Linux.

Instalacja sprzętu

1. Wyłącz komputer, monitor(y) oraz inne urządzenia peryferyjne.
2. Wyjmij kabel zasilający komputera, a następnie odłącz wszystkie kable z tyłu komputera.
3. Otwórz obudowę komputera.
UWAGA: W razie potrzeby skonsultuj instrukcję obsługi komputera, aby uzyskać pomoc w zdejmowaniu obudowy.
4. Wyjmij istniejącą kartę graficzną z komputera.
5. Znajdź odpowiedni slot PCI-E x16 i, jeśli to konieczne, usuń odpowiadające mu metalowe pokrywy tylne. Upewnij się, że wszystkie wewnętrzne kable są wolne od slotu.
6. Dopasuj kartę graficzną do slotu i naciskaj ją mocno, aż zostanie całkowicie osadzona.
7. Jeśli karta wymaga zasilania dodatkowego i musi być bezpośrednio podłączona do zasilacza, znajdź odpowiednie kable zasilające zasilacza i podłącz je do złącz zasilania dodatkowego karty graficznej. Wszystkie połączenia zasilania muszą być podłączone, aby karta graficzna działała.
8. Przyskręć kartę graficzną za stałe do panelu tylnego.
9. Upewnij się, że żadne wewnętrzne kable nie przeszkadzają w komponentach wewnątrz komputera (np. wentylatorze chłodzącym), a następnie zamontuj z powrotem obudowę komputera.
10. Podłącz ponownie wszystkie kable, które odłączyłeś podczas instalacji, a następnie podłącz kabel zasilający komputera. Włącz monitor, a następnie komputer.

Oprogramowanie AMD Radeon

1. **Ważna uwaga przed rozpoczęciem.** Karta musi być zainstalowana fizycznie przed zainstalowaniem sterownika i oprogramowania. Sterownik nie zostanie zainstalowany bez fizycznej instalacji karty i przesyłania sygnału do monitora.

UWAGA: Podczas pierwszego uruchomienia systemu Windows, karta zostanie przypisana do standardowego sterownika graficznego VGA przez system Windows. Jest to normalne i umożliwia korzystanie z systemu do czasu zainstalowania sterownika Radeon.

2. **Pobierz najnowszy sterownik** Przejdź bezpośrednio na stronę [<http://support.amd.com>] (<http://support.amd.com>) i pobierz najnowszy sterownik dla karty graficznej. AMD regularnie publikuje aktualizacje sterowników, więc zaleca się pobranie sterownika bezpośrednio z tej strony.