GAMESIR ENGLISH

GAMESIR G8+ MFi
Wired Game Controller

Scan the code for more tutorials ➡
https://gamesir.com/pages/manuals-gamesir-g8-mfi

PACKAGE CONTENTS
G8+ MFi Controller *1 Small Thumbstick *1 Heightened Thumbstick *1
Round Thumbstick *1 User Manual *1 Thank You & After-sale Service Card *1
GameSir Sticker *1 Certification *1 Thick Silicone Pad *2

COMPATIBILITY
• Type-C-enabled Device

DEVICE LAYOUT



BASIC FUNCTION INTRODUCTION

CONNECTION

1	Connect the controller's Type-C connector with the phone's port.	
2	Extend the controller and place the phone in.	
3	Retract the controller to complete the connection.	

BASIC OPERATION

Power On	The controller will automatically power on when connected to the device via the moveable Type-C connector.
Power Off	The controller will automatically power off when disconnected from the device.
Standby	The controller will automatically power off if no operation is detected within 10 minutes while connected. In standby mode, press any A/B/X/Y/Home button to power on.

* Some Android phones need to enable the OTG function to power and use the controller.

PLATFORM AND MODE

PLATFORM	MODE	INDICATOR LIGHT	SWITCHING METHOD
iOS	MFi Mode	White	Automatically switches when connected to an iOS device.
Android	Android Mode	Dark Blue	Automatically switches when connected to an Android device.
	G-Touch Mode	Light Blue	Launch within the GameSir app.
PC	Xbox Mode	Green	Automatically switches when connected to a Windows PC.

* When connected to a PC or Android device, press and hold (•••)+(≡) for 2 seconds to force switch between Android mode and Xbox mode.

ADVANCED TUTORIAL

BUTTON COMBINATION

FUNCTION	BUTTON COMBINATION	DESCRIPTION
Back Button Settings	Press and hold for 2 seconds (M)+(M1)/(M2)	Press and hold the M button and M1/M2 button simultaneously until the corresponding direction's light flashes white. Then, press the button to be programmed to complete the setting. * During the setting process, if you press the corresponding back button directly, its button value will be cleared.
Toggle Hair Trigger Mode	Press and hold for 2 seconds (M)+(L2)/(R2)	Toggle between enabling and disabling the hair trigger mode.
Switch Mode	Press and hold for 3 seconds (•••)+(≡)	Switch between Android mode and Xbox mode. * Only works when connected to a PC or Android device.
Switch Layout	Press and hold for 3 seconds (M)+(A)	Swap the button values of A-B and X-Y. The controller will vibrate to indicate when the swapping is successful.
Adjust Volume	Press and hold (Home)+D-pad up/down	Increase/decrease system volume. Only works in Android mode and MFi Mode.
Adjust Vibration Intensity	Press and hold (M)+D-pad up/down	Increase/decrease the vibration intensity level.

STICKS & TRIGGERS CALIBRATION
Press and hold (•••)+(≡)+(Home) simultaneously to enter calibration mode. The indicator light will flash white during this process. At this point, push both sticks all the way down to their limits and rotate them 2-3 times. Press both triggers fully down 3 times. Finally, press (A) to exit. The indicator light will return to its normal state, indicating that the calibration is complete.

ACCESSORY REPLACEMENT
The GameSir-G8+ MFi faceplate features a magnetic and interchangeable design. After removing it, you can replace the thumbstick according to your personal preference. More replacement accessories will be released in the future for gamers to choose from. Stay tuned.

* The ABXY buttons use a magnetic design, allowing users to pull them out and switch the layout between the two layouts shown.

SILICONE PAD REPLACEMENT

GameSir-G8+ MFi features a swappable silicone pad design on the right side, allowing users to customize the pad thickness based on their device. When installing, ensure the thicker side of the silicone pad faces upward and the thinner side faces downward.

1. For devices without a protective case, use the thick silicone pads.
2. For devices with a protective case, use the thin silicone pads.
3. Ensure the edges of the silicone pads fit securely against the controller to prevent them from falling off.



CUSTOMIZE CONFIGURATION VIA THE "GAMESIR" APP
Go to the gamesir.com website on your phone or scan the QR code on the right to download the "GameSir" app

PLEASE READ THIS PRECAUTIONS CAREFULLY
- CONTAINS SMALL PARTS. Keep out of reach of children under the age of 3. Seek immediate medical attention if swallowed or inhaled.
- DO NOT use the product near fire.
- DO NOT expose to direct sunlight or high temperatures.
- DO NOT leave the product in a humid or dusty environment.
- DO NOT impact the product or cause it to fall due to strong impact.
- DO NOT touch USB port directly or it might cause malfunctions.
- DO NOT strongly bend or pull cable parts.
- Use a soft, dry cloth while cleaning.
- DO NOT use chemicals such as gasoline or thinner.
- DO NOT disassemble, repair or modify.
- DO NOT use for purposes other than its original purpose. We are NOT responsible for accidents or damage when used for non-original purposes.
- DO NOT look directly at the optical light. It might damage your eyes.
- If you have any quality concerns or suggestions, please contact GameSir or your local distributor.

WASTE ELECTRICAL & ELECTRICAL EQUIPMENT INFORMATION
CORRECT DISPOSAL OF THIS PRODUCT (WASTE ELECTRICAL & ELECTRICAL EQUIPMENT)

Applicable in the European Union and other European countries with separate collection systems. This mark on the product or accompanying documents means that it should not be mixed with general household waste. For proper treatment, recovery and recycling, please take this product to designated collection points where it will be accepted free of charge. Alternatively, in some countries you may be able to return your products to your local retailer upon purchase of an equivalent new product. Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling. Business users should contact their supplier for further information. If you do so, you will ensure that your disposed product undergoes the necessary treatment, recovery and recycling, thereby preventing negative potential effects on the environment and human health.

DECLARATION OF CONFORMITY

FCC STATEMENT
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CE STATEMENT OF COMPLIANCE WITH EU DIRECTIVE
Hereby, Guangzhou Chicken Run Network Technology Co., Ltd. declares that this GameSir G8+ MFi Controller is in compliance with Directive 2014/30/EU & 2011/65/EU and its amendment (EU) 2015/863.

WARNINGS AND SAFETY INFORMATION
All information regarding the use of the products can be found in the attached user manual. Before using the product, please read the manual carefully and follow the manufacturer's recommendations.
Also, please review the following safety information and warnings before use:

USAGE WARNINGS
RISK OF DEVICE DAMAGE:
- Controllers should be used exclusively for their intended purpose—video games. Do not use the device for any purpose other than those recommended by the manufacturer.
- If the device comes into contact with liquid, immediately disconnect it and dry it according to the manufacturer's instructions.
- Avoid applying excessive force when pressing buttons or operating the controller to prevent damage to the mechanisms.

RISK TO THE USER:
- During extended use, take regular breaks to avoid fatigue in your hands, wrists, and shoulders.
- Ensure the controller is placed securely to prevent it from slipping or tipping over during use.
- Controllers with force feedback systems may generate sudden movements—always hold them with both hands while playing.

POWER AND CONNECTION RISKS:
- Do not use damaged power cables or USB cables. Always use the original accessories provided by the manufacturer.
- Ensure that USB ports and power sockets are clean and free of debris to ensure a proper connection.
- For wireless devices, regularly charge the batteries or replace them with new ones to ensure continuous operation.

PROPER USAGE INFORMATION
PREPARATION AND SETUP:
- Before first use, install any software or drivers provided by the manufacturer if required.
- Place the controller on a stable surface, such as a desk, to ensure comfort and precision during use.

Make sure all cables are properly connected and secured to prevent accidental disconnections.

SAFE USAGE:
- Adjust the device settings in games (e.g., sensitivity, vibrations) according to your preferences to ensure comfort and avoid strain on your hands or shoulders.
- Regularly check the condition of buttons, joysticks, and other components to ensure they are functioning properly.
- For controllers with force feedback, ensure the feedback settings are not too strong.

ADDITIONAL PRECAUTIONS:
- **Cleaning and Maintenance:** Regularly remove dust from the controller using a dry, soft cloth. Avoid using harsh chemicals that may damage the surface of the device.
- **Storage:** After use, disconnect the controller from the console or PC and store it in a dry, dust-free place.
- **Cable Management:** For wired controllers, ensure cables are organized to prevent tangling or damage.

COMPLIANCE DECLARATION
Controllers are designed in accordance with the safety requirements outlined in Regulation (EU) 2023/988. They meet the requirements for electromagnetic compatibility (EMC), durability, and user safety.
This manual is a translation of the original user manual created by the manufacturer.
Detailed information regarding the distributor/manufacturer warranty conditions is available on the website: www.gamesir.com
The product must be regularly maintained (cleaned) by the user or through specialized service points at the user's cost and responsibility. If the user manual does not provide information about necessary periodic or service maintenance actions, the physical condition of the product should be assessed regularly (at least once a week) to detect any deviation from the condition of a new product. If any deviation is detected or identified, immediate maintenance (cleaning) or servicing actions should be taken. Failure to perform proper maintenance (cleaning) and respond to identified issues may result in permanent damage to the product. The warranty provider is not responsible for damages resulting from neglect.
EU Company: ENIF PEGASUS S.R.L.
Address: Str. RADOVANU, Nr. 7, Bloc 42, Scara 1, Etaj 5, Apartament 29, 22882Bucuresti Sectorul 2, Romaia
Producer: Guangzhou Chicken Run Network Technology Co., Ltd.
Address: Room 1001&1003, No. 19, Yard 2, Yuancun West Street, Tianhe District, Guangzhou, China
GameSir and the GameSir logo are registered trademarks of Guangzhou Chicken Run Network Technology Co., Ltd. All other trademarks are the property of their respective owners.

LI-ION BATTERY
The device is equipped with a LI-ION (lithium-ion) battery, which, due to its physical and chemical structure, ages over time and with usage. The manufacturer specifies the maximum operating time of the device under laboratory conditions (new battery, fully charged). Actual usage time may differ from the declared value and this is not considered a defect of the device. To maintain the maximum lifespan of the battery, it is not recommended to discharge it below 3.18V or 15% of its total capacity. Lower values, such as 2.5V for the cell, permanently damage the battery and are not covered by the warranty. If the battery or the entire device is not used for more than one month, the battery should be charged to 50%, and the charge level should be checked regularly every two months. Store the battery and device in a dry place, away from direct sunlight and negative temperatures.

LI-PO BATTERY
The device is equipped with a LI-PO (lithium-polymer) battery, which, due to its physical and chemical structure, ages over time and with usage. The manufacturer specifies the maximum operating time of the device under laboratory conditions (new battery, fully charged). Actual usage time may differ from the declared value and this is not considered a defect of the device. To maintain the maximum lifespan of the battery, it is not recommended to discharge it below 3.5V or 5% of its total capacity. Lower values, such as 3.2V for the cell, permanently damage the battery and are not covered by the warranty. If the battery or the entire device is not used for more than one month, the battery should be charged to 50%, and the charge level should be checked regularly every two months. Store the battery and device in a dry place, away from direct sunlight and negative temperatures.