





AMBILIGHT tv
Quick Start Guide
MLED901 Series










Tool needed
for assembly



x2




55\"/>




A Desk Placement



B Wall Placement




Recommended Wall Distance



B

	A	B	C	D	E	F	G	H	I	J	K	L	M (kg)	N (kg)
55"	1226.2	705.3	63.4	985	278	300	200	463.1	378.5	4xM6	10-22	Ⓚ+★	11.7	12.16
65"	1445.7	828.7	66	1221	311	300	300	572.8	473.4	4xM6	10-15	Ⓚ+★	15.85	16.31



4 Get Connected


www.philips.to/smartTV

The Philips Smart TV app lets you switch channels and adjust the volume - just like a remote control.

5 Register and Support

www.philips.com/tvsupport

Register your TV, find out more, download the user manual and get support



English Read the safety instructions.

Български Прочетете инструкциите за безопасност.

Čeština Přečtěte si bezpečnostní pokyny.

Hrvatski Pročitajte sigurnosne upute.

Dansk Læs sikkerhedsforskrifterne.

Deutsch Lesen Sie die Sicherheitshinweise.

Ελληνικά Διαβάστε τις οδηγίες ασφαλείας.

Eesti Lugege ohutusnõudeid.

Español Lea las instrucciones de seguridad.

Français Lisez les consignes de sécurité.

Italiano Leggere le istruzioni di sicurezza.

Қазақша Қорғаныстық нұсқаулар.

Latviešu Izlasiet drošības norādījumus.

Lietuvių Perskaitykite saugos instrukcijas.

Magyar Olvassa el a biztonsági utasításokat.

Nederlands Lees de veiligheidsvoorschriften.

Norsk Les sikkerhetsforskriftene.

Polski Zapoznaj się z instrukcjami bezpieczeństwa.

Português Leia as instruções de segurança.

Română Citiți instrucțiunile de siguranță.

Русский Читайте инструкции по технике безопасности.

Srpski Pročitajte bezbednosna uputstva.

Slovenščina Preberite varnostna navodila.

Slovenský Prečítajte si bezpečnostné pokyny.

Suomi Lue turvaohjeet.

Svenska Läs säkerhetsinstruktionerna.

ภาษาไทย โปรดอ่านคำแนะนำด้านความปลอดภัย

Türkçe Güvenlik talimatlarını okuyun.

Українська Читайте інструкції з техніки безпеки.

العربية قراءة تعليمات السلامة.

עברית קראו את הוראות הבטיחות.

FSC Logo
H:12mm

FEUILLE
Séparez les éléments avant de briser

1

To install batteries, slide the battery door up.

2

Use 2x AAA (Alkaline) LR03 1.5V (included)

3

Slide battery door back in place.

1 2 3 4

COMMON INTERFACE

USB 2

USB 1

HDD

POWER (EU)

POWER (UK)

SAT (EU)

TV ANTENNA

HDMI 1

HDMI 2 ARC/eARC

HDMI 3/4

DIGITAL AUDIO OUT

NETWORK

Ultra High-speed HDMI cable


COAXIAL

SATELLITE COAXIAL

TOSLINK

HDMI eARC

ROUTER



!