

Strona główna » awei » Instrukcja obsługi bezprzewodowych słuchawek dousznych AWEI T26

zawartość

1 bezprzewodowe słuchawki douszne AWEI T26

2 Zawartość opakowania

3 W skrócie

Sterowanie 4 przyciskami

5 Rozwiązywanie problemów

6 SPECYFIKACJA

7 BEZPIECZEŃSTWO I GWARANCJA

8 GWARANCJA

9 Dokumenty / Zasoby

9.1 Odniesienia

10 Powiązanych Postów







Słuchawki bezprzewodowe AWEI T26



Zawartość opakowania






1. Bezprzewodowe słuchawki douszne x 1 para (L/P)
2. Etui ładujące 1
3. Końcówki douszne x 3 pary (S/M/L; końcówki douszne w rozmiarze M, wstępnie zamontowane)
4. Kabel ładujący USB-C x 1|
5. Instrukcja obsługi x 1
6. Szybki przewodnik x 1


Na pierwszy rzut oka

Etui ładujące





Earbuds



Przewodnik po wskaźnikach LED słuchawek dousznych

System State	Indicator Activity
Pairing	Flashes red and white alternately
Connected	Flashes white once every 8 seconds
Being charged	Solid red
Fully charged	Off
Low battery	Flashes red twice every 5 seconds with voice prompt

Instrukcja obsługi wskaźnika LED etui ładującego

Otwórz etui ładujące, aby sprawdzić poziom naładowania akumulatora.

Battery Level	Indicator Activity
60%-100% battery	The 3 indicators stay white for 3 seconds
20%-60% battery	The first 2 indicators stay white for 3 seconds
0%-20% battery	The first indicator stays white for 3 seconds
Low Battery	The first indicator flashes white 5 times

Uwaga: Wskaźnik ładowania świeci na czerwono, gdy etui ładujące jest ładowane, i gaśnie po pełnym naładowaniu.

Korzystanie ze słuchawek dousznych

Podczas pierwszego użycia słuchawek dousznych należy zdjąć folię izolacyjną ze styków ładujących słuchawek.

Naładuj słuchawki douszne

1. Umieść słuchawki w etui ładującym.
2. Zamknij pokrywę obudowy.

Naładuj etui ładujące

1. Podłącz mniejszy koniec kabla USB-C do portu USB-C etui ładującego.
2. Podłącz drugi koniec do ładowarki ściennej USB lub włączonego komputera (DC 5 V).

 Uwagi: Pełne naładowanie słuchawek dousznych zajmuje około 1,5 godziny. Przed pierwszym użyciem należy w pełni naładować słuchawki douszne i etui ładujące. Słuchawki douszne i etui ładujące ładują się jednocześnie. Etui ładujące można używać jako samodzielnej ładowarki.

Włączanie i wyłączanie

Włączanie: Otwórz etui ładujące.

Wyłączanie: Włóż słuchawki douszne z powrotem do etui ładującego i zamknij pokrywę.

Uwaga: Gdy słuchawki douszne są ładowane w etui ładującym, a etui jest rozładowane, słuchawki douszne włączą się automatycznie.

Para

1. Upewnij się, że słuchawki douszne i urządzenie Bluetooth znajdują się obok siebie lub w odległości nie większej niż 3 stopy i nie ma między nimi żadnych przeszkód.
2. Otwórz etui ładujące. Słuchawki automatycznie się włączą i przejdą w tryb parowania.
3. Włącz Bluetooth w swoim urządzeniu Bluetooth.
4. Na liście znalezionych urządzeń Bluetooth w Twoim urządzeniu Bluetooth wybierz „T26”, aby je sparować.

Uwagi:

- Słuchawki przejdą w tryb parowania zaraz po pierwszym włączeniu.
- Za każdym razem, gdy włączysz słuchawki, będą one automatycznie łączyć się z ostatnio podłączonym urządzeniem, jeśli będzie ono znajdowało się w zasięgu Bluetooth.
- Jeśli słuchawki są założone, ale nie są sparowane z urządzeniem Bluetooth, wyłączą się automatycznie po 5 minutach.
- Tryb mono: Po połączeniu Bluetooth możesz używać tylko jednej słuchawki dousznej, wkładając drugą do etui ładującego i zamykając pokrywę.



Sterowanie przyciskami

Function	What to do
Play / Pause	Double-tap the touch button of either earbud.
Previous / Next track	Triple-tap the touch button of the left / right earbud.
Answer / End a call	Double-tap the touch button of either earbud.
Reject a call	Tap and hold the touch button of either earbud for 2 seconds.
Activate / Deactivate Siri or other voice assistant software	Tap and hold the touch button of the LEFT earbud for 2 seconds. Tap and hold the touch button for 2 seconds when using one earbud.

ANC function

Tap and hold the touch button of the RIGHT earbud for 2 seconds to enable/disable the ANC function.

Note: You cannot use the ANC function when using one earbud.

Reset the earbuds

1. Put the earbuds back into the charging case and the earbuds indicators stay red.
2. Wait that the earbuds indicators flash red once.
3. Tap the touch buttons of both earbuds 5 times simultaneously and the indicator of the right earbud flashes white 3 times.



Cleaning the Earbuds and Charging Case

The earbuds and charging case may require periodic cleaning.

Earbud nozzles	Clean only with a dry, soft cotton swab or equivalent. Note: Never insert any cleaning tool into the nozzle.
Charging pins (on earbuds and case)	To prevent rusting, regularly clean with a dry, soft cotton swab or equivalent.
Charging case	Clean only with a dry, soft cotton swab or equivalent.

Trouble Shooting

Q: Pairing fails.

1. A: Put the earbuds back in the charging case and the earbuds are being charged.
2. Take the earbuds out of the case and earbuds enter pairing mode.
3. Choose “T26” on your phone to pair.

If the pairing still fails, check the following points:

- Make sure the earbuds and your Bluetooth device are next to each other or within 3 feet and there are no obstacles between them.
- There is no signal interference nearby (check the “Connection is not stable” part for signal interference conditions).
- Try to reboot your Bluetooth device.

Q: I paired the earbuds with my phone before, but I failed to pair them with my phone again.

A: Turn on the Bluetooth of your phone and in my DEVICES”, choose “T26” and tap “O”> “Forget This Device”. Then pair the earbuds with your phone again.

Q: The connection is not stable.

A: Bluetooth signal is transmitted wirelessly and signals can be affected, which results in the intermittent sound of earbuds, in the following conditions: The distance between the earbuds and your Bluetooth device is at the edge of the Bluetooth pairable distance. Transmitted signals encounter obstacles or human body blockage. There are high-power electronic devices nearby. There are other Bluetooth devices that are being turned on/ off nearby. To resume a stable connection between the earbuds and your Bluetooth device, try to avoid the above conditions and do the pairing again following the steps in the pairing fails part.

Q: When playing music, the left and right earbuds cannot be synchronized.

A: Tap and hold the touch button of the RIGHT earbud for 2 seconds to enable/ disable the ANC function and the two earbuds will be synchronized.

SPECIFICATION

Model	T26
Bluetooth Version	V5.0
Battery	35mAh (each earbud), 620mAh (charging case)
Charging Time	Approximately 1.5 hours (earbuds), 1.5 hours (charging case)
Waterproof Rate	IPX4
Input	DC 5V/1A
Playtime (varies by volume level and content)	Up to 5 hours per charge, 30 hours with charging case (ANC on) Up to 6 hours per charge, 36 hours with charging case (ANC off)
Bluetooth Range	10 m / 33 ft.
Supporting Protocols	A2DP / HFP / HSP / AVRCP
Working Temperature	-10°C to 40°C

SAFETY AND WARRANTY

Important safety instructions

- Use of earbuds will impair your ability to hear other sounds. Use caution while using your earbuds when you are engaging in any activity that requires your full attention.
- If you have a pacemaker or other electrical medical devices, consult your physician before using this product.
- This product is not a toy never allows children to play with this product. The bags themselves or the many small parts they contain may cause choking if ingested.

- Never try to dismantle the product yourself, or push objects of any kind into the product, as this may cause short circuits which could result in a fire or electric shock.
- None of the components can be replaced or repaired by users. Only authorized dealers or service centers may open the product.
- Avoid exposing your product to heat and humidity to protect against damage to the product or injury to you.
- Keep all products, cords, and cables away from operating machinery.
- If the product overheats, is dropped or damaged, has a damaged cord or plug, or has been dropped in a liquid, discontinue use and contact us.
- Do NOT use in areas where there are explosive hazards.
- Do NOT submerge the product in water. Do NOT expose the product to moving water (e.g., from a faucet, etc.).
- Do NOT wear the earbuds while showering or bathing, or when participating in water sports, e.g., swimming, waterskiing, surfing, etc.
- Leaving the product in hot or cold places, such as in a closed car in the summer and winter conditions, will reduce the capacity and lifetime of the earbuds.
- Use of a power supply or charger that is not recommended or sold by a power pack manufacturer may result in risk or fire or injury.
- Do not use the charging case in excess of its output range.
- Do not use a charging case that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- Dispose of the product according to local standards and regulations.

Remember: Always drive safely, avoid distractions and follow local laws! Using the earbuds while operating a motor vehicle, motorcycle, watercraft or bicycle may be dangerous, and is illegal in some jurisdictions, just as the use of the earbuds with both ears covered while driving is not permitted in certain jurisdictions. Check your local laws. Use caution while using your earbuds when you are engaging in any activity that requires your full attention. While engaging in any such activity, removing the earbuds from your ear or turning off your earbuds will keep you from being distracted, so as to avoid accident or injury. Do not take notes or read documents while driving.

WARRANTY

We strive to build our products with the highest attention to detail and craftsmanship. However, sometimes there are occurrences of a defect, so we are happy to offer a ONE-year hassle-free warranty to all our devices as we continue to make amazing products. Please contact us if you have any questions about our devices.

	AWEI T26 Wireless Earbuds [pdf] User Manual T26, 2AW9K-T26, 2AW9KT26, T26 Wireless Earbuds, Wireless Earbuds
--	--

References

- [User Manual](#)

[Manuals+](#) | [Prześlij](#) | [Głębokie wyszukiwanie](#) | [Polityka prywatności](#) | [@manuals.plus](#) | [YouTube](#)

Ta strona internetowa jest niezależną publikacją i nie jest ani powiązana, ani popierana przez żadnego z właścicieli znaków towarowych. Znak słowny „Bluetooth®” i logo są zarejestrowanymi znakami towarowymi należącymi do Bluetooth SIG, Inc. Znak słowny „Wi-Fi®” i logo są zarejestrowanymi znakami towarowymi należącymi do Wi-Fi Alliance. Jakiegokolwiek użycie tych znaków na tej stronie internetowej nie oznacza żadnego powiązania ani poparcia.

