

[Strona główna](#) » [Edifier](#) » Instrukcja obsługi głośnika bezprzewodowego
EDIFIER MS50A 

EDIFIER®

MS50A

GŁOŚNIK BEZPRZEWODOWY

Instrukcja obsługi



zawartość

- 1 Przegląd produktu**
- 2 Co znajduje się w pudełku**
- 3 Operacja**
- 4 Połączenie Bluetooth**
- 5 Rozwiązywanie problemów**
- 6 Załącznik**
- 7 Dokumenty/zasoby**
 - 7.1 Odniesienia**
- 8 powiązanych postów**

Przegląd produktu

Dziękujemy za wybór EDIFIER! Aby zapewnić prawidłowe działanie urządzenia, prosimy o dokładne zapoznanie się z niniejszą instrukcją przed użyciem.

Uwaga:

- Informacje zawarte w niniejszym dokumencie mogą ulec zmianie w dowolnym momencie bez wcześniejszego powiadomienia.
- MS50A to aktywny głośnik wykorzystujący technologie bezprzewodowe Wi-Fi i Bluetooth. Jego głównym zastosowaniem jest odtwarzanie multimediów strumieniowych online w oparciu o Amazon Alexa (Współpraca z

Alexą). Po zarejestrowaniu głośnika w Amazon Alexa za pomocą konta Amazon, będziesz mógł korzystać z serwisów streamingowych, takich jak Spotify, Amazon Music, Pandora itp. Głośnikiem można sterować za pomocą aplikacji Alexa, a także za pomocą interaktywnych urządzeń głosowych, takich jak Echo.

Dzięki Alexie możesz tworzyć własne playlisty, sterować odtwarzaniem/pauzą, budować system multiroom z innymi urządzeniami oraz łączyć dwa głośniki w grupę stereo.

- MS50A jest kompatybilny z Apple AirPlay.
- Głośnik można podłączyć do telefonu, komputera itp. w celu bezprzewodowego odtwarzania muzyki przez Bluetooth.
- Aby skonfigurować urządzenie i od razu cieszyć się muzyką, skorzystaj z przewodnika szybkiego startu (dołączonego do zestawu).



Co jest w pudełku

- ⚙️ Otwórz pudełko i sprawdź, czy zawiera następujące elementy:



Speaker



Quickstart guide



Power cable

Notatka:

- Proszę używać kabla zasilającego dołączonego do zestawu.

Działanie

Sterowanie przyciskami:



① Przełącznik trybu:

Naciśnij: przełącznik trybu audio

Naciśnij i przytrzymaj przez 3 sekundy:

Połączenie Wi-Fi

(model Wi-Fi)

Parowanie Bluetooth

(tryb Bluetooth)

② Poprzedni utwór

③ Następny utwór

④ Pauza/odtworzenie

Naciśnij i przytrzymaj przez 6 sekund: przywróć ustawienia fabryczne

⑤ Włączanie/wyłączanie/

wyciszanie Naciśnij: wyciszanie/włączanie

dźwięku Naciśnij i przytrzymaj przez 1,5 sekundy: włączanie/wyłączanie

⑥ Przesuń przeciwnie do ruchu wskazówek zegara: zmniejszanie głośności

⑦ Przesuń zgodnie z ruchem wskazówek zegara: zwiększanie głośności


Wskaźniki:



(1) Biała dioda LED: tryb Wi-Fi

Państwo	Opis	Funkcje
Mrugaj szybko	3 mrugnięcia na sekundę	Gotowy do połączenia z nową siecią Wi-Fi
Stałe światło	Stałe światło	Połączono z Wi-Fi
Bicie serca	Długie i krótkie mrugnięcia na przemian	Wi-Fi rozłączone
Migać	1 mrugnięcie na sekundę	Niemy


(2) Niebieska dioda LED: tryb Bluetooth



Państwo	Opis	Funkcje
Mrugaj szybko	3 mrugnięcia na sekundę	Parowanie Bluetooth
Stałe światło	Stałe światło	Połączenie Bluetooth
Migać	1 mrugnięcie na sekundę	Niemy

(3) Niebieska i biała dioda LED migają naprzemiennie: uruchamianie/wyłączanie i aktualizacja oprogramowania sprzętowego





Państwo	Opis	Funkcje
Mrugaj szybko	Blue and white LED-lit and off alternately and rapidly	starting up / over the air firm ware update


Brightness of indicators

1. Unconnected to network: low brightness;
2. Connected to network:

Day time (7 am to 9 pm): full brightness

Nighttime (9 pm to 7 am): low brightness

Connection:



Wi-Fi connection

1. Please download the “Edifier Home” App to a compatible phone or tablet from the App Store/Google Play Store or from www.edifier.com;
2. When powered on for the first time, this speaker will automatically enter Wi-Fi connection mode (white LED blinking rapidly). To reset the Wi-Fi connection, press the “...” button to

switch to Wi-Fi mode (white LED), then press and hold the “...” button for 3s to enter Wi-Fi connection mode again;

3. Open the Edifier Home App, follow the instructions to add a device, and connect the speaker to the network;
4. Once connected, a steady white LED will be lit; 5. This speaker can work with Alexa, after it is connected to the network, the Edifier Home App will prompt you to register this speaker to your Amazon Alexa account, please follow the instructions to complete the registration.

Bluetooth connection

1. Power on this speaker and wait for it to start up (approximately 20 seconds). Press the “...” button to switch to Bluetooth mode (blue LED).
2. This speaker is in Bluetooth pairing mode when the blue LED blinks rapidly, please select “EDIFIER MS50A” to connect.
3. Blue LED will lit steadily after pairing is complete, now you can play music on the paired device.

Stereo group and multi-room system setup:

Stereo group setup:

You can use two MS50A to build a stereo group for a better music experience.

1. Make sure two MS50A speakers are connected to the same network as your mobile device;
2. To set up stereo group, open the Edifier Home App, tap “Stereo group” on the home screen and click to add, then follow the instructions to build a stereo group;
3. Set the two speakers as the left and right channel output respectively and rename the stereo group.
4. To cancel the stereo group, open the Edifier Home App, select the stereo group you want to cancel, and follow the instructions to cancel the stereo group.



Multi-room system setup:

After this speaker is registered in the Amazon Alexa, you can add it to a multi-room system through the Alexa App and play music/podcasts/ news on multiple speakers simultaneously.

1. Preparations: Connect this speaker to the same network as the other “work with Alexa” speakers, and ensure they are logged in to the same Amazon Alexa account.

2. Setup: Open the Alexa App, switch to the Device interface, follow the instructions to join the existing multi-room system, or create a new multi-room system. Please see the relevant instructions of the Alexa App for details.

Stereo group and multi-room system setup:

Music playback:

1. Online steaming media playback

1. For Amazon Music, Spotify, Pandora, TuneIn, iHeartRadio and other music services linked to Alexa, after relevant accounts are linked, you can play through Alexa and control this speaker by using other interactive voice devices like Echo.
2. This speaker has passed Spotify Connect certification, and you can select to play on this speaker in the Spotify App;
3. This speaker has passed Apple AirPlay 2 certification and can be air-played by using iPhone, iPad, iMac, and other devices.

2. Local playback

For local playback devices, you can connect them to this speaker through Bluetooth for playback, or use Apple AirPlay or Spotify Connect to play through Wi-Fi.

Volume control:

The volume can be controlled in the following ways:

1. The touch panel on this speaker: In Wi-Fi or Bluetooth mode, volume the level can be controlled through the touch panel on this speaker, please see the touch panel control instructions;
2. Edifier Home App: Click the device already connected to network and enter the playing control interface for volume control;
3. Interactive voice devices: Under the same network, use interactive voice devices like Echo logging in the same Amazon account to control volume through voice commands.

System update and restore to factory settings

System update

Open the Edifier Home App, select the speaker to update, look for the firmware version code in the “

Restore to factory settings

Press and hold the “

pairing and Amazon account registration information will all be cleared, meanwhile, this speaker will return to Wi-Fi mode and the volume will resume to 50% level.

Troubleshooting



Cannot find “MS50A” in Bluetooth mode?

1. Check if the speaker is ON.
2. Ensure the speaker is switched to Bluetooth mode.
3. Disconnect from any Bluetooth device by pressing and holding the “...” button, then search for “MS50A” again.
4. Turn off the speaker and restart it, then switch to Bluetooth mode and search for “MS50A” again.



No sound

1. Tell if the main power is connected, or if the wall outlet is switched on.
2. Ensure the audio cables are firmly connected and the input is set correctly on the speaker.
3. Check if there is a signal output from the audio source.
4. Try to turn up the volume using the volume control.
5. Turn off the speaker and restart it.

Appendix

Specifications

Power output: mid-bass+treble: 25W+15W

Frequency response: 52Hz-18KHz

Audio input: Wi-Fi, Bluetooth

Declaration for EU

⚙️ Frequency Band (Bluetooth): 2.402GHz ~ 2.480GHz

Frequency Band (2.4G): 2.400GHz ~ 2.4835GHz

Frequency Band (5G): 5.15GHz ~ 5.35GHz, 5.47GHz ~ 5.725GHz, 5.725GHz ~ 5.85GHz

RF Power output: ≤20 dBm (EIRP) (5.725GHz~5.850GHz excluded)

RF Power output: ≤14 dBm (EIRP) (5.725GHz~5.850GHz)

			
@Edifiernglobal	@Edifier_Global	@Edifier_Global	edifier.com/support

Model: EDF100008
FCC ID: Z9G-EDF112
IC: 10004A-EDF112
Edifier International Limited
P.O. Box 6264
General Post Office
Hong Kong
Tel: +852 2522 6989
Fax: +852 2522 1989

www.edifier.com
© 2021 Edifier International Limited. All rights reserved.
Printed in China

NOTICE:
For the need of technical improvement and system upgrade, the information contained herein may be subject to change from time to time without prior notice. Products of EDIFIER will be customized for different applications. Pictures and illustrations shown on this manual may be slightly different from the actual product. If any difference is found, the actual product prevails.





EDIFIER™

M550A
WIRELESS SPEAKER
User manual



1. Product overview

Thank you for choosing EDIFIER. For correct operations, please carefully read this manual before use.

- Information contained herein may be subject to change from time to time without prior notice.

- M550A is an active speaker using both Wi-Fi and Bluetooth wireless technologies. The core architecture is online streaming media playback based on Amazon Alexa (link with Alexa). After registering this speaker to Amazon Alexa with an Amazon account, you will be able to use streaming services such as Spotify, Amazon Music, Pandora, etc. The speaker can be controlled in Alexa App as well as using interactive voice devices such as Echo. With Alexa, you can control your personal playlist, control play/pause, build a multi-room system with other devices, and build two speakers to a stereo group.

- The M550A is compatible with Apple AirPlay.
- This speaker can be connected to phones, PC, etc. for wireless playback via Bluetooth.
- You can refer to the "Quickstart" Guide included in the box to set up and enjoy your music right away.



2. What's in the box

Open the box and ensure the following items are included:



- Please use the power cable included in the box.

3. Operation

Button controls:



Indicators:

(1) White LED: Wi-Fi mode			
State	Description	Functions	
Blink rapidly	3 blinks per second	Ready to connect to a new Wi-Fi network	
Steady lit	Steady lit	Wi-Fi connected	
Heartbeat	Long and short blink alternately	Wi-Fi disconnected	
Blink	1 blink per second	Mute	
(2) Blue LED: Bluetooth mode			
State	Description	Functions	
Blink rapidly	3 blinks per second	Bluetooth pairing	
Steady lit	Steady lit	Bluetooth connected	
Blink	1 blink per second	Mute	
(3) Blue and white LED blinks alternately: starting up/off and firmware update			
State	Description	Functions	
Blink rapidly	Blue and white LED lit up alternately and rapidly	Starting up /over the air firmware update	
Brightness of indication			
(1) Unconnected to network: low brightness;			
(2) Connected to network:			
Day time (on to bright, full brightness)			
Night time (on to dim, low brightness)			

Connection:



Wi-Fi connection

- Please download the "Edifier Home" App to a compatible phone or tablet from the App Store/Google Play Store or from www.edifier.com.
- When powered on for the first time, this speaker will automatically enter Wi-Fi connection mode (white LED blinks rapidly). To use Wi-Fi connection, press the "Wi-Fi" button to switch to Wi-Fi mode (white LED), then press and hold the "Wi-Fi" button for 3s to enter Wi-Fi connection mode again.
- Open the Edifier Home App, follow the instructions to add a device, and connect the speaker to network.
- Once connected, a steady white LED will be lit.
- This speaker can work with Alexa when it is connected to network. After Home App will prompt you to register this speaker to your Amazon Alexa account. Please follow the instructions to complete the registration.

Bluetooth connection

- Please turn this speaker and use for the first time (approximately 20 seconds). Press the "Bluetooth" button to switch to Bluetooth mode (blue LED).
- This speaker is in Bluetooth pairing mode when blue LED blinks rapidly (please select "EDIFIER M550A" to connect).
- Blue LED will be steady after pairing is completed, now you can play music on the paired device.

Stereo group and multi-room system setup:

- Stereo group setup:**
- You can use two M550A to build a stereo group for better music experience.
- Make sure two M550A speakers are connected to the same network as your mobile device.
 - To setup stereo group, open the Edifier Home App, tap "Stereo group" on the home screen and click to add, then follow the instructions to build a stereo group.
 - Set the two speakers as the left and right channel output respectively and rename the stereo group.
 - To cancel the stereo group, open the Edifier Home App, select the stereo group you want to cancel, and follow the instructions to cancel the stereo group.

Multi-room system setup:

- After the speaker is registered in the Amazon Alexa, you can add it to a multi-room system through the Alexa App and play music probably from other multi-room speakers simultaneously.
- Preparation: Connect this speaker to the same network as the other "hook with Alexa" speakers, and ensure they are logged in to the same Amazon Alexa account.
 - Setup: Open the Alexa App, switch to the Device interface, follow the instructions to join the existing multi-room system, or create a new multi-room system. Please see relevant instructions of the Alexa App for details.

Stereo group and multi-room system setup:

Music playback:

1. Online streaming media playback

- For Amazon Music, Spotify, Pandora, TuneIn, iHeartRadio and other music services linked to Alexa, after relevant accounts are linked, you can play through Alexa and control this speaker by using other interactive voice devices like Echo.
- This speaker has passed Spotify Connect certification, and you can use it to play on the speaker in the Spotify App.
- This speaker has passed Apple Music 2 certification, and can be controlled using iPhone, iPad, Mac and other devices.

2. Local playback

- For local playback devices, you can connect them to this speaker through Bluetooth for playback, or use Apple AirPlay or Spotify Connect to play through Wi-Fi.

Volume control:

- The volume can be controlled in the following ways:
- Touch panel on the speaker: In Wi-Fi or Bluetooth mode, volume level can be controlled through the touch panel on the speaker, please see the touch panel control instructions.
 - Edifier Home App: Click the device already connected to network and enter the playing control interface for volume control.
 - Interactive voice devices: Under the same network, use the interactive voice devices like Echo logging in the same Amazon account to control volume through voice commands.

System update and restore to factory settings

System update

- Open the Edifier Home App, select the speaker to update, look for the

[EDIFIER MS50A Wireless Speaker](#) [pdf] User Manual

MS50A, Wireless Speaker, MS50A Wireless Speaker



EDIFIER™

M550A
WIRELESS SPEAKER
User manual



1. Product overview

Thank you for choosing EDIFIER. For correct operations, please carefully read this manual before use.

- Information contained herein may be subject to change from time to time without prior notice.

- M550A is an active speaker using both Wi-Fi and Bluetooth wireless technologies. The core architecture is online streaming media playback based on Amazon Alexa (link with Alexa). After registering this speaker to Amazon Alexa with an Amazon account, you will be able to use streaming services such as Spotify, Amazon Music, Pandora, etc. The speaker can be controlled in Alexa App as well as using interactive voice devices such as Echo. With Alexa, you can create your personal playlist, control play/pause, build a multi-room system with other devices, and build two speakers to a stereo group.

- The M550A is compatible with Apple AirPlay.
- This speaker can be connected to phones, PC, etc. for wireless playback via Bluetooth.
- You can refer to the "Quickstart" Guide included in the box to set up and enjoy your music right away.



2. What's in the box

Open the box and ensure the following items are included:



- Please use the power cable included in the box.

3. Operation

Button controls:



(1) White LED: Wi-Fi mode			
State	Description	Functions	
Blink rapidly	3 blinks per second	Ready to connect to a new Wi-Fi network	
Steady lit	Steady lit	Wi-Fi connected	
Heartbeat	Long and short blink alternately	Wi-Fi disconnected	
Blink	1 blink per second	Mute	
(2) Blue LED: Bluetooth mode			
State	Description	Functions	
Blink rapidly	3 blinks per second	Bluetooth pairing	
Steady lit	Steady lit	Bluetooth connected	
Blink	1 blink per second	Mute	
(3) Blue and white LED blinks alternately: starting up/off and firmware update			
State	Description	Functions	
Blue and white LED lit up alternately	Starting up / over the air firmware update		
Blink rapidly			
Brightness of indication			
(1) Unconnected to network: low brightness;			
(2) Connected to network:			
Day time (on to bright, full brightness)			
Night time (on to dim, low brightness)			

Connection:



Wi-Fi connection:

- Please download the "Edifier Home" App to a compatible phone or tablet from the App Store/Google Play Store or from www.edifier.com.
- When powered on for the first time, this speaker will automatically enter Wi-Fi connection mode (white LED blinks rapidly). To use Wi-Fi connection, press the "Wi-Fi" button to switch to Wi-Fi mode (white LED). Then press and hold the "Wi-Fi" button for 3s to enter Wi-Fi connection mode again.
- Open the Edifier Home App, follow the instructions to add a device, and connect the speaker to network.
- Once connected, a steady white LED will be lit.
- This speaker can work with Alexa when it is connected to network. The Edifier Home App will prompt you to register this speaker to your Amazon Alexa account. Please follow the instructions to complete the registration.

Bluetooth connection:

- Place on this speaker and use for the first time (approximately 20 seconds). Press the "Bluetooth" button to switch to Bluetooth mode (blue LED).
- This speaker is in Bluetooth pairing mode when blue LED blinks rapidly (please select "EDIFIER M550A" to connect).
- Blue LED will be steady after pairing is completed, now you can play music on this paired device.

Stereo group and multi-room system setup:

Stereo group setup:

You can use two M550A to build a stereo group for better music experience.

- Make sure two M550A speakers are connected to the same network as your mobile device.
- To setup stereo group, open the Edifier Home App, tap "Stereo group" on the home screen and click to add, then follow the instructions to build a stereo group.
- Set the two speakers as the left and right channel output respectively and name the stereo group.
- To cancel the stereo group, open the Edifier Home App, select the stereo group you want to cancel, and follow the instructions to cancel the stereo group.

Multi-room system setup:

After the speaker is registered in the Amazon Alexa, you can add it to a multi-room system through the Alexa App and play music probably from other multi-room speakers simultaneously.

- Preparation: Connect this speaker to the same network as the other "hook with Alexa" speakers, and ensure they are logged in to the same Amazon Alexa account.
- Setup: Open the Alexa App, switch to the Device interface, follow the instructions to join the existing multi-room system, or create a new multi-room system. Please see relevant instructions of the Alexa App for details.

Stereo group and multi-room system setup:

Music playback:

1. Online streaming media playback:

- For Amazon Music, Spotify, Pandora, TuneIn, iHeartRadio and other music services linked to Alexa, after relevant accounts are linked, you can play through Alexa and control this speaker by using other interactive voice devices like Echo.
- This speaker has passed Spotify Connect certification, and you can stream to play on the speaker in the Spotify App.
- This speaker has passed Apple AirPlay 2 certification, and can be controlled using iPhone, iPad, Mac and other devices.

2. Local playback:

For local playback devices, you can connect them to this speaker through Bluetooth for playback, or use Apple AirPlay or Spotify Connect to play through Wi-Fi.

Volume control:

The volume can be controlled in the following ways:

- Touch panel on the speaker: In Wi-Fi or Bluetooth mode, volume level can be controlled through the touch panel on the speaker, please see the touch panel control instructions.
- Edifier Home App: Click the device already connected to network and enter the playing control interface for volume control.
- Interactive voice devices: Under the same network, use the interactive voice devices like Echo logging in the same Amazon account to control volume through voice commands.

System update and restore to factory settings

System update

Open the Edifier Home App, select the speaker to update, look for the

firmware version code in the "D" interface, and upgrade to the latest firmware when the "A" icon appears. Please see relevant instructions of the Edifier Home App for details.

Restore to factory settings

Press and hold the "H" button on this speaker for 6s or click "Restore to factory settings" in the Edifier Home App to restore to factory settings. Please note that QoS, connectivity, Bluetooth pairing and Amazon account registration information will all be deleted irreversibly. The speaker will return to default mode and the volume will require to 50% level.

4. Troubleshooting

4.1 Troubleshooting

4.2 Cannot find "MESSAGE" in Bluetooth mode?

1. Check if the speaker is ON.
2. Ensure the speaker is switched to Bluetooth mode.
3. Disconnect from any Bluetooth device by pressing and holding the "H" button, then search for "MESSAGE" again.
4. Turn off the speaker and restart it, then switch to Bluetooth mode and search for "MESSAGE" again.

4.3 No sound

1. Check if main power is connected, or if the wall outlet is switched on.
2. Ensure the audio cables are firmly connected and the input is set correctly on the speaker.
3. Check if there is a signal output from the audio source.
4. Try to turn up the volume using the volume control.
5. Turn off the speaker and restart it.

5. Appendix

Specifications

Power output: mid bass-tweeter: 25W+15W
Frequency response: 50Hz-15KHz
Audio input: Hi-Fi, Bluetooth

Declaration for EU

Frequency Band Bluetooth: 7.402GHz ~ 7.480GHz
Frequency Band Bluetooth: 2.402GHz ~ 2.483GHz
Frequency Band Bluetooth: 5.180GHz ~ 5.392GHz, 5.472GHz ~ 5.725GHz, 5.725GHz ~ 5.850GHz
RF Power output: <10 dBm (EIRP) (5.725GHz-5.850GHz) excluded
RF Power output: <10 dBm (EIRP) (5.725GHz-5.850GHz)

Model: E2P-1000B
MSR: 30, 300, 100, 110
IC: 1000A, E2P-112

Edifier International Limited
P.O. Box 6284
Geneva Post Office
Switzerland

Tel: +41 22 522 0888
Fax: +41 22 522 0889
www.edifier.com
© 2021 Edifier International Limited. All rights reserved.
- Printed in China

NOTE:
Due to the need of technical improvement and system upgrade, information contained herein may be subject to change from time to time without prior notice. Products of E2P-1000B will be continued for different applications. Pictures and illustrations shown on this manual may be slightly different from actual product. If any difference is found, the actual product prevails.

References

- [User Manual](#)

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

Niniejsza strona internetowa jest niezależną publikacją i nie jest powiązana ani wspierana przez żadnego z właścicieli znaków towarowych. Znak słowny i logo „Bluetooth®” są zastrzeżonymi znakami towarowymi należącymi do Bluetooth SIG, Inc. Znak słowny i logo „Wi-Fi®” są zastrzeżonymi znakami towarowymi należącymi do Wi-Fi Alliance. Jakikolwiek użycie tych znaków na tej stronie internetowej nie oznacza żadnego powiązania ani wsparcia.