

Instrukcje+ — Uprozczone instrukcje obsługi.



Poly 5220 Black Wire Stereo USB C Headset



HP Poly 5220 Czarny przewód Stereo USB C Instrukcje zestawu słuchawkowego

[Strona główna](#) » [HP](#) » HP Poly 5220 Black Wire Stereo USB C Headset
Instrukcje 

zawartość

- 1 hp Poly 5220 Czarny przewód stereofoniczny USB C Headset**
- 2 Instrukcje bezpieczeństwa**
- 3 Przegląd**
- 4 Konfiguracja**
- 5 Dopasowanie**
- 6 Podstawy**
- 7 Rozwiązywanie problemów**
- 8 Najczęściej zadawane pytania**
- 9 Kontakt**
- 10 Dokumenty/zasoby**
 - 10.1 Odniesienia**





HP Poly 5220 Czarny przewód Stereo USB C Headset



Instrukcje bezpieczeństwa

Aby zmniejszyć ryzyko pożaru, porażenia prądem, obrażeń ciała i uszkodzenia mienia, przeczytaj wszystkie instrukcje obsługi i poniższe instrukcje bezpieczeństwa przed użyciem produktu Poly. Temperatura pracy, przechowywania i ładowania wynosi od 10°C do 40°C (od 50°F do 104°F).

- Używaj wyłącznie produktów i akcesoriów Poly przeznaczonych do stosowania z tym produktem.
- Jeśli po użyciu produktu wystąpi podrażnienie skóry, należy przerwać stosowanie produktu i skontaktować się z firmą Poly.
- DZIECI. Nigdy nie pozwalaj dzieciom bawić się produktem – małe części mogą stwarzać ryzyko zadławienia.
- Nie rozmontowuj produktu, ponieważ może to narazić Cię na niebezpieczne napięcia lub inne zagrożenia. Nieprawidłowy ponowny montaż może spowodować porażenie prądem lub pożar, gdy produkt będzie następnie używany.
- Odłącz produkt od zasilania, przerwij jego używanie i skontaktuj się z firmą Poly, jeśli produkt się przegrzeje lub jeśli jego obudowa, przewód lub wtyczka zostaną uszkodzone.
- Narażenie na wysoki poziom głośności dźwięku lub nadmierne ciśnienie akustyczne może spowodować tymczasowe lub trwałe uszkodzenie słuchu. Chociaż nie ma jednego ustawienia głośności, które byłoby odpowiednie dla wszystkich, należy zawsze używać zestawu słuchawkowego/słuchawek z głośnością ustawioną na umiarkowanym poziomie i unikać długotrwałego narażenia na wysoki poziom głośności dźwięku. Im głośniejszy dźwięk, tym mniej czasu potrzeba, aby słuch mógł ucierpieć. Możesz doświadczać różnych poziomów dźwięku podczas korzystania z zestawu słuchawkowego/słuchawek z różnymi urządzeniami. Urządzenie, którego używasz i jego ustawienia wpływają na poziom słyszanego dźwięku. Jeśli odczuwasz dyskomfort słuchu, powinieneś przestać słuchać urządzenia



przez zestaw słuchawkowy/słuchawki i udać się do lekarza na badanie słuchu. Aby chronić słuch, niektórzy eksperci ds. słuchu sugerują, aby:

1. Przed założeniem zestawu słuchawkowego/słuchawek na uszy ustaw regulator głośności na niską wartość i ustaw możliwie najniższą głośność.
2. Unikaj zwiększania głośności, aby zablokować głośne otoczenie. Zawsze, gdy to możliwe, używaj zestawu słuchawkowego/słuchawek w cichym otoczeniu z niskim poziomem hałasu w tle.
3. Ogranicz czas korzystania ze słuchawek przy wysokim poziomie głośności.
4. Zmniejsz głośność, jeśli dźwięk z zestawu słuchawkowego/słuchawek uniemożliwia Ci słyszenie osób mówiących w pobliżu. Więcej informacji na temat zestawów słuchawkowych/słuchawek i słuchu można znaleźć na [stronie poly.com/healthandsafety](https://poly.com/healthandsafety).

- If you use your headset/headphones while driving, check local laws regarding use of a mobile phone and headset, and ensure your attention and focus remain on driving safely. Use of a headset/headphones that covers both ears will impair your ability to hear other sounds and in most regions is illegal to use while operating a motor vehicle or riding a bicycle and may be a serious hazard for you and others.
 - If this product includes earbuds/eartips, install and use them in accordance with the instructions provided.
Do not force earbuds/eartips down the ear canal. Consult a doctor if they become lodged in the ear canal.
-  • Plug the mains adapter or charger into a socket outlet that is near to the equipment and will be easily accessible.

Battery Warnings for Wireless Products

- If your product has an embedded, non-replaceable battery, do not attempt to open the product or remove the battery as this may cause injury and/or

damage the product. If your product has a replaceable battery, use only the battery type supplied by Poly. Remove a spent battery promptly.

- Replace rechargeable batteries after three years or 300 charge cycles, whichever occurs first.
- Do not dispose of the product or battery in a fire or heat above 40°C (104°F).
- Do not expose the battery to extremely high temperatures. It may result in an explosion or the leakage of flammable liquid or gas.
- Do not open, deform or mutilate the battery. There may be corrosive materials which can cause damage to eyes or skin and may be toxic if swallowed.
- Never put batteries in mouth. If swallowed, contact a physician or poison control center.
- Swallowing may lead to burns, perforation of soft tissue, and death. Severe burns can occur within 2 hours of ingestion.
- Always store batteries where children cannot reach them.
- Do not allow any battery or its holder to contact metal objects such as keys or coins.
- RECYCLING The product battery must be recycled or disposed of properly. Contact your local recycling center for battery removal and proper disposal.
- Use only the charger supplied by Poly to charge the product and follow the charging instructions provided.

Alternatively, if your headset is designed to be charged with your cell phone

⚙ :charger, use only cell phone chargers approved and provided by your cell phone manufacturer. Do not use the charger for any other purpose.

Ensure that the voltage rating corresponds to the power supply you intend to use.

MFi

Use of the Made for Apple badge means that an accessory has been designed to connect specifically to the Apple product(s) identified in the badge, and has

been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

EU Declaration of Conformity

Hereby, HP Inc. declares that the product described in the accompanying documentation is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. A copy of the Declaration of Conformity to the essential requirements may be found at poly.com/conformity.

EU WEEE Statement

A crossed-out wheellie bin symbol denotes that waste electrical and electronic equipment and batteries must not be disposed of as unsorted municipal waste, but collected separately. For more detailed information, please go to poly.com

France Specific Absorption Rate (SAR/DAS)

In accordance with France Specific Absorption Rate disclosure, this product SAR is: DAS/SAR < 0.3 W/Kg.

UK Declaration of Conformity

Hereby, HP Inc. UK Ltd. declares that the equipment types as described in the accompanying documentation is in compliance with the relevant statutory requirements. A copy of the Declaration of Conformity to the essential requirements may be found at poly.com/conformity.



China RoHS

- www.poly.com/rohs

India RoHS

- India's "E-waste Rules" are compliant and does not contain restricted materials over the threshold, unless permitted.

Taiwan RoHS

- www.poly.com/rohs

UK Declaration of Conformity

Hereby, HP Inc. UK Ltd. declares that the equipment types as described in the accompanying documentation is in compliance with the relevant statutory requirements. A copy of the Declaration of Conformity to the essential requirements may be found at poly.com/conformity.



Overview



Setup

Power on your headset by connecting to your computer or mobile device via USB or 3.5 mm connector.

IMPORTANT Ensure that your 3.5 mm connector is fully connected to the headset controller



Load software

Customize your device behavior through advanced settings and options with the Poly Lens Desktop App. Some softphones require the installation of Poly software to enable device call control (answer/end and mute) functionality.

Download: poly.com/lens.

NOTE Device settings are also available in Plantronics Hub Desktop App.

Update your Poly device

Keep your firmware and software up-to-date to improve performance and add new features to your Poly device.

Update your device using your computer with the Poly Lens Desktop App.

Download at

poly.com/lens

While updating:

- Do not use your Poly device until the update is complete.
- Do not start a second update from a second device.
- Do not stream media.
- Do not answer or place a call.

Fit

Adjust the headband

Lengthen or shorten the band until it fits comfortably. The cushions should sit comfortably over the center of your ears



Position the boom

The headset can be worn with the boom on your left or right side. For true stereo listening, wear the boom on your left side. Rotate the boom to align with your mouth.



Adjust the boom

Gently bend the boom in or out so it is approximately one finger width from the corner of your mouth.

Basics

Make/take/end calls

Headset call control is a software feature and is dependent on a compatible softphone. If you have not installed Poly Lens Desktop App (poly.com/lens) or do not have a compatible softphone, press the headset call button first and then make/take/end the call using the softphone application.



- Answer or end a call

Tap the Call button or use your softphone.

- Make a call

Dial using your softphone application.

- Redial

When not on an active call, double-tap the call button to redial the last call.

- Hold

Double-tap the Call button to put a call on hold.

Volume

- **Listening volume**

Press the Volume up (+) or Volume down (-) button.

- **Adjust headset microphone volume (softphone)**

Place a test softphone call and adjust the softphone volume and PC sound volume accordingly.

Mute

- During a call, briefly press the mute button to mute the microphone on the inline controller. To unmute press the button again.

Troubleshooting

Headset

I hear a high-pitched noise when wearing the headset.

- Ensure that your 3.5 mm connector is fully connected to the \headset controller.

cannot hear caller.

- The listening volume is too low. Press the volume up button on the headset. and/or ensure that the volume setting on your computer is set accurately.
- Your headset is not set as the default audio device. Use the audio settings in your sound control panel/preferences to select your headset as the

default audio device.

- Ensure that your 3.5 mm connector is fully connected to the headset controller.

Callers cannot hear me.

- Headset is muted. Tap the mute button to unmute the microphone.
- The headset microphone boom aligned incorrectly. Align the headset boom with your mouth.
- Your headset is not set as the default Voice device. Use the audio settings in your sound control panel/preferences to change the input device.
- Ensure that your 3.5 mm connector is fully connected to the headset controller.

The sound in the headset is distorted.

- Lower the listen volume on your softphone until the distortion disappears.

I can hear an echo in the headset.

- Adjust volume on the headset.
- Ensure that your 3.5 mm connector is fully connected to the headset controller.



When I use my headset with a softphone, the headset call control and mute buttons don't work.

- Make sure the softphone you are using is supported by viewing www.plantronics.com/softphonecompatibility.
- If required to enable headset control (answer/end and mute) functionality, ensure you have Poly Lens Desktop App installed. See Load software.

- Your mobile device may not support call control functionality. Check with device manufacturer.

The other headset I was using to listen to music does not work anymore.

- Your headset will set itself as the default audio device in Windows. Use the audio settings in your sound control panel/ preferences to change the audio device.

My phone is not finding my headset during a call or while listening to music.

- Podczas rozmowy telefonicznej lub słuchania muzyki upewnij się, że dźwięk jest kierowany do wybranego zestawu słuchawkowego, przechodząc do ustawień i upewniając się, że jest to ustawienie domyślne.

Często zadawane pytania

- **P: Czy mogę używać zestawu słuchawkowego Poly Blackwire 5220 ze swoim smartfonem?**
 - O: Tak, zestaw słuchawkowy jest kompatybilny ze smartfonami wyposażonymi w port USB-C lub 3,5 mm.
- **P: Jak dostosować głośność w zestawie słuchawkowym?**
 - A: Możesz regulować głośność za pomocą wbudowanych elementów sterujących na słuchawkach. Po prostu naciśnij przyciski Volume +/-, aby zwiększyć lub zmniejszyć głośność.
- **P: Czy zestaw słuchawkowy Poly Blackwire 5220 nadaje się do wideokonferencji?**
 - O: Tak, zestaw słuchawkowy idealnie nadaje się do wideokonferencji, ponieważ oferuje redukcję szumów, czystą jakość dźwięku i wygodę noszenia podczas dłuższych spotkań.



Kontakt

- POTRZEBUJESZ WIĘCEJ POMOCY?
- poly.com/wsparcie
- Plantronics, Inc. Plantronics BV
- 345 Ulica Encinal
- Santa Cruz, Kalifornia 95060
- Stany Zjednoczone
- Skorpion 171
- 2132 LR Hoofddorp
- Niderlandy

© 2021 Plantronics, Inc. Wszelkie prawa zastrzeżone. Poly, projekt śmigła i logo Poly są znakami towarowymi Plantronics, Inc. Wszystkie inne znaki towarowe są własnością ich właścicieli. Wyprodukowano przez Plantronics, Inc. 209253-06 06.21

Dokumenty / Zasoby

	hp Poly 5220 Czarny przewód Stereo USB C Headset [pdf] Instrukcje Poly 5220 Czarny przewód Stereo USB C Headset, Poly 5220, Czarny przewód Stereo USB C Headset, Przewód Stereo USB C Headset, Stereo USB C Headset
--	---

Odniesienia

- [Instrukcja obsługi](#)

Manuals+ , Polityka prywatności

Ta strona internetowa jest niezależną publikacją i nie jest ani powiązana, ani popierana przez żadnego z właścicieli znaków towarowych. Znak słowny „Bluetooth®” i logo są zarejestrowanymi znakami towarowymi należącymi do Bluetooth SIG, Inc. Znak słowny „Wi-Fi®” i logo są zarejestrowanymi znakami towarowymi należącymi do Wi-Fi Alliance. Jakiegokolwiek użycie tych znaków na tej stronie internetowej nie oznacza żadnego powiązania ani poparcia.

