

 Put the "Left Lifting Column" and "Right Lifting Column with Motor" on the ground.
 Screw the "Main Beam" on both columns.



Bag # 2 x6 Bag # 0 M6 x1

2 Stand the columns right up and screw the "Column Foots."



Bag # 🗗		x8	Bag # 쥗	x4
Bag # 🖲	\bigcirc	x4	Bag # 1 Tools	x1



5 Install the

Install the "Cover of Drive Rod" with "Holders."



Bag # 🔁		x4	Bag # 윌		x2	Bag # 1 Tools	M6	x 1
---------	--	----	---------	--	----	-------------------------	----	-----

Install the "Desktop."



Bag # 🖨	x6	Bag # 🗗	0	x6	Bag # 1 Tools	M6	x1



Stand the structure

"Bracket for Power Unit."

Bag # 🕘

4

x6

Insert the "Drive Rod" and install the

Bag # **1** Tools

M6

x1





HOW TO CONNECT





Locate the Power Unit into the Bracket after connecting.



x1





FUNCTION & TROUBLESHOOTING	DISPLAY	INSTRUCTION
Reset the Lifting System	888	Press " \checkmark " to the lowest height. Then release the button and press " \checkmark " for 5 seconds, it will show "rSt" and press " \checkmark " again. It will display the lowest height to complete the reset.
Lock the Height Adjustment	888	Press "▲" and "✔" simultaneously for 5 seconds.
Unlock the Height Adjustment		Press "▲" and "♥" simultaneously for 5 seconds again.
Height Memory	9 88	Firstly, press " \bigstar " or " \checkmark " to adjust the height. While the height is as expected, press the "number" button for 3 seconds to memorize the height with the corresponding button.
Overheat Protection	888	While the lifting unit is over-loading, the height adjustment will automatically inoperable for protection, please wait for 15~20 minutes.
Temporary Malfunction	888	 1.Follow the "rSt" procedure. Press "♥" to the lowest height. Then release the button and press "♥" for 5 seconds, it will show "rSt" and press "♥" again. It will display the lowest height to complete the reset. If the issue remains, follow the next step. 2.Unplug the AC plug.Check every connection followed by the manual and examine the connectors. 3.Re-connect the AC and Reset the desk.If the malfunction issue remains, please contact the distributor for after-service. Do not fix or open the system by yourself.



CAUTION

Make sure no obstacles are in the desk's path.

It is highly suggested to avoid the human underneath as the height movement. The physical injuries from height adjustment are excluded from the after-service.

GLOBAL WARRANTY POLICY

WARRANTY PERIODS OF COUGAR GAMING DEVICES Product : ROYAL MOSSA Electric Standing Desk Warranty : 1 Year

This warranty gives you specific legal rights. You may also have other rights granted under local law. These rights may vary.

WARRANTY AGREEMENT

If the product has defects in material or manufacture, COUGAR will provide product repair and replacement service within the warranty period.
Our warranty service is based on the date of the invoice or warranty card.

CONDITIONS WHERE FREE MAINTENANCE IS NOT PROVIDED

Any fault or damage caused by natural disasters (including storm, fire, flood, thunder, earthquake, etc).
Any fault or damage caused by accidental factors and man-made reasons (including hit, scrape, crash, moving, compression, stain, corrosion, riot, misuse, malicious damage, etc).

 Use in an improper operating environment (including high temperature, high humidity, water inflow, etc).
 Inability to provide the product warranty card, purchase receipt or invoice to prove the product is still within the warranty period and the shipping date of the product is out of warranty. •The warranty card has been altered or its number is hard to identify.

•The warranty period has expired. •Any fault or damage caused by non-compliance with regulations stated on the user manual or improper, rough and careless treatment.

 Any fault or damage caused by use of parts not certified by COUGAR original manufacturer.
 The problem is caused by improper repair or adjustment by the buyer or any manufacturer without authorization from COUGAR.

• The product is not acquired from an authorized distributor of the company or is acquired from illicit sources. • Paper carton, instruction and other accessories are not warranted.

DISCLAIMERS

•COUGAR products should not be used as critical components in life support devices. • COUGAR products another back of the and timb or damage of the and timb or damage or loss of property caused by or during COUGAR products' use as or with medical equipment, military equipment, traffic equipment and disaster

prevention systems. •COUGAR's warranty liability is limited to repair or replacement. The decision on whether to repair or replace belongs exclusively to COUGAR.

• COUGAR is, to the extent not prohibited by law, not liable for any damages; expenses; lost data, revenues, savings or profits; or any incidental or consequential damages happened while the use of a defective product from COUGAR or due to its use.

WARNING

• Please wear protective gloves when assembling the Desk. It is your own responsibility to use

Do not use abrasive products or scrub energetically when cleaning. Please stick to gentle products

suitable for delicate materials. •All parts should be checked monthly to confirm their integrity and to make sure that the screws

are not loose. If any part of the product is or appears to be damaged, missing or loose, please contact the local distributor and do not use the product. WARNING

LEGAL NOTICES

This manual was created by Compucase Enterprise and may not be completely or partially copied, passed on, distributed or stored without written consent by Compucase Enterprise. COUGAR® is a registered brand of Compucase Enterprise Other product and company names mentioned in this documentation may be brands or trademarks of their respective owners. Compucase Enterprise reserves the right to make changes concerning the contents of the manual and the technical data of the product without previous announcement.

MANUFACTURER CONTACT LOYALTY FOUNDER ENTERPRISE CO., LTD. 13F, NO.859, Jingguo Rd, Taoyuan Taiwan TEL:+886-3-3269123

Service email : https://cougargaming.com/support/contact/upload/ Made in China





www.cougargaming.com

