



MAD DOG



LAMPKA NA MONITOR GML200K

Instrukcja obsługi
i warunki gwarancji

GML200K MONITOR LIGHT

Operating Manual
& Warranty Terms

WARUNKI BEZPIECZEŃSTWA I ZAGROŻENIA

1. Nie uruchamiaj urządzenia jeżeli jest uszkodzone, w przeciwnym razie może dojść do porażenia prądem.
2. Należy chronić produkt przed zanieczyszczeniami, wilgocią i przegrzaniem.
3. Niniejszy sprzęt może być użytkowany przez dzieci w wieku co najmniej 8 lat i przez osoby o obniżonych możliwościach fizycznych, umysłowych i osoby o braku doświadczenia i znajomości sprzętu, jeżeli zapewniony zostanie nadzór lub instruktaż odnośnie użytkowania sprzętu w bezpieczny sposób i zrozumiałe związane z tym zagrożenia. Dzieci nie powinny bawić się sprzętem. Nie powinno być wykonywane czyszczenie i konserwacja sprzętu przez dzieci bez nadzoru.
4. Nie należy zanurzać urządzenia w wodzie oraz innych płynach.
5. Produktu nie należy stosować w połączeniu z włącznikami elektrycznymi, czasowymi, fotokomórkami itp.
6. Produktu należy używać wyłącznie w suchych pomieszczeniach.
7. Dzieci nie mogą zajmować się czyszczeniem ani konserwacją bez nadzoru dorosłych.
8. Urządzenie można podłączyć tylko do źródła zasilania o napięciu i częstotliwości zgodnej ze specyfikacją na tabliczce znamionowej.
9. Urządzenie jest przeznaczone tylko do użytku domowego. Producent nie ponosi odpowiedzialności za szkody powstałe w wyniku niewłaściwego lub niezgodnego z przeznaczeniem użytkowania.
10. Nie ciągnąć ani nie przenosić urządzenia za przewód. Nie używać przewodu jako uchwytu.

11. Nie używać w wilgotnych miejscach takich jak łazienki. W przypadku dostania się cieczy do urządzenia należy je wyłączyć oraz zlecić przegląd autoryzowanemu centrum serwisowania sprzętu.
12. Nie używać detergentu do czyszczenia urządzenia.
13. Odłączając urządzenie ze źródła zasilania nie należy ciągnąć za kabel. Należy chwycić wtyczkę ręką i odłączyć urządzenie.
14. Nie należy odłączać urządzenia mokrymi rękami.
15. W przypadku, gdy pojawi się ból głowy lub oczu, należy wyłączyć lampkę i zrobić sobie kilkuminutową przerwę. Należy zachować odpowiednią odległość od bezpośredniego źródła światła.
16. Produkt może nie działać prawidłowo w sytuacji, gdy znajdzie się w zasięgu pola elektromagnetycznego.
17. Źródło światła w lampce nie jest wymieniane. Po osiągnięciu końca źródła światła lampę należy wymienić na nową.
18. Ten produkt zawiera źródło światła o klasie efektywności energetycznej <F>.

WPROWADZENIE

Dziękujemy za zaufanie, jakim nas Państwo obdarzyli, dokonując zakupu urządzenia marki **MAD DOG**.

Jesteśmy przekonani, że to bardzo dobrej jakości urządzenie zapewni Państwu dużo radości i satysfakcji z jego użytkowania.

NALEŻY DOKŁADNIE PRZECZYTAĆ INSTRUKCJĘ OBSŁUGI I JEJ PRZESTRZEGAĆ!


To urządzenie jest przeznaczone do użytku domowego lub podobnego, niedotyczącego celów komercyjnych.


Producent nie ponosi odpowiedzialności za szkody powstałe w wyniku użytkowania niewłaściwego lub niezgodnego z przeznaczeniem.

DANE TECHNICZNE

MODEL	GML200K
Wejście [V/A]	5V/1A
Moc znamionowa [W]	5W
Temperatura barwowa [K]	3000 – 6500K
Produkt posiada źródło światła o klasie efektywności energetycznej	F
Żywotność [h]	25000h
Regulacja jasności	5 poziomów
Zasilanie regulatora	3 x Bateria AAA
Strumień świetlny [lm]	285
Maksymalna moc częstotliwości radiowej	-2,27 dBm
Zakres częstotliwości	2400 – 2483,5 MHz

OPIS URZĄDZENIA







PIERWSZE URUCHOMIENIE I OBSŁUGA

Zamontuj lampkę na monitorze używając uchwyty, tak aby była stabilna i podłącz kabel zasilający, który jest dołączony do zestawu.

SPOSÓB MOCOWANIA LAMPKI NA RÓŻNEJ GRUBOŚCI MONITORACH



Do pilota bezprzewodowego włóż baterię i zamknij obudowę.



Instalacja baterii

Korzystając z pilota bądź bezpośrednio na lampce naciśnij przycisk  aby uruchomić urządzenie. Następnie dopasuj jasność i temperaturę za pomocą przycisku  oraz barwę za pomocą przycisku . Na pilocie możesz dostosować jasność i temperaturę za pomocą suwaka. Możesz również włączyć tryb automatyczny, który będzie sam dopasowywał jasność na podstawie poziomu światła w pomieszczeniu za pomocą ikony .

CZYSZCZENIE I KONSERWACJA

UWAGA! PRZED CZYSZCZENIEM WYŁĄCZ URZĄDZENIE I ODŁĄCZ OD ZASILANIA.

Zaleca się, aby do czyszczenia ściągnąć lampkę z monitora.

Czyścić należy tylko i wyłącznie suchą ścierką.

UWAGA! NE MYJ URZĄDZENIA WODĄ, NIE UŻYWAJ ŚRODKÓW CHEMICZNYCH, PONIEWAŻ MOGĄ ONE POWODOWAĆ ODBARWIENIA.

DEKLARACJA

ART-DOM Sp. z o.o. niniejszym oświadcza, że GML200K jest zgodny z odpowiednimi wymaganiami unijnego prawodawstwa harmonizacyjnego: dyrektywą 2014/53/UE i innym unijnym prawodawstwem harmonizacyjnym. Pełny tekst deklaracji zgodności UE jest dostępny pod następującym adresem:

<https://www.artdom.net.pl/deklaracja/GML200K/>

PROBLEMY I ROZWIĄZANIA

PROBLEM	PRZYCZYNA	ROZWIĄZANIE
Lampka nie działa.	Lampka nie jest podłączona prawidłowo.	Upewnij się, że lampka jest prawidłowo podłączona
	Uszkodzony przewód.	Upewnij się, że przewód nie jest uszkodzony.
	Rozładowanie baterie w pilocie	Wymień baterie zgodnie z sekcją pierwsze uruchomienie i obsługa
Lampka jest zbyt ciemna.	Ustawienia jasności są zbyt niskie.	Sprawdź i dostosuj ustawienia jasności.
Lampka nie reaguje na dotyk.	Brud lub kurz na panelu dotykowym.	Oczyść panel dotykowy suchą ściereczką.

EKOLOGICZNA I PRZYJAZNA DLA ŚRODOWISKA UTYLIZACJA

To urządzenie jest oznaczone, zgodnie z Dyrektywą Parlamentu Europejskiego i Rady 2012/19/UE z dnia 4 lipca 2012 r. w sprawie zużytego sprzętu elektrycznego i elektronicznego (WEEE), symbolem przekreślonego kontenera na odpady:



Nie należy wyrzucać urządzeń oznaczonych tym symbolem, razem z odpadami domowymi.

Urządzenie należy zwrócić do lokalnego punktu przetwarzania i utylizacji odpadów lub skontaktować się z władzami miejskimi.

MOŻESZ POMÓC CHRONIĆ ŚRODOWISKO!

Właściwe postępowanie ze zużytym sprzętem elektrycznym i elektronicznym przyczynia się do uniknięcia szkodliwych dla zdrowia ludzi i środowiska naturalnego konsekwencji, wynikających z obecności składników niebezpiecznych oraz niewłaściwego składowania i przetwarzania takiego sprzętu.

WARUNKI GWARANCJI DOTYCZĄCE LAMPKI

- ART-DOM Sp. z o.o. z siedzibą w Łodzi (92-402) przy ul. Zakładowej 90/92 Numer Krajowego Rejestru Sądowego 0000354059 (Gwarant) gwarantuje, że zakupione urządzenie jest wolne od wad fizycznych. Gwarancja obejmuje tylko wady wynikające z przyczyn tkwiących w rzeczy sprzedanej (wady fabryczne).
- Ujawniona wada zostanie usunięta na koszt Gwaranta w ciągu 14 dni od daty zgłoszenia uszkodzenia do serwisu autoryzowanego lub punktu sprzedaży.

3. W wyjątkowych przypadkach, np. konieczności sprowadzenia części zamiennych od producenta, termin naprawy może zostać wydłużony do 30 dni.
4. Okres gwarancji dla użytkownika wynosi 24 miesiące od daty wydania towaru.
5. Towar przeznaczony jest do używania wyłącznie w warunkach indywidualnego gospodarstwa domowego.
6. Gwarancja nie obejmuje:
 - a. uszkodzeń powstałych na skutek używania urządzenia niezgodnie z instrukcją obsługi,
 - b. uszkodzeń mechanicznych, chemicznych lub termicznych,
 - c. napraw i modyfikacji dokonanych przez firmy lub osoby nieposiadające autoryzacji producenta,
 - d. części z natury łatwo zużywalnych lub materiałów eksploatacyjnych takich jak: baterie, żarówki, bezpieczniki, filtry, pokrętła, półki, akcesoria,
 - e. instalacji, konserwacji, przeglądów, czyszczenia, odblokowania, usunięcia zanieczyszczeń oraz instruktażu.
7. O sposobie usunięcia wady decyduje Gwarant. Usunięcie potwierdzonej wady urządzenia nastąpi poprzez wykonanie naprawy gwarancyjnej lub wymianę urządzenia. Gwarant może dokonać naprawy, gdy kupujący żąda wymiany lub Gwarant może dokonać wymiany, gdy kupujący żąda naprawy, jeżeli doprowadzenie do zgodności towaru (urządzenia) zgodnie z udzieloną gwarancją w sposób wybrany przez kupującego jest niemożliwe albo wymagałoby nadmiernych kosztów dla Gwaranta. W szczególnie uzasadnionych wypadkach, jeżeli naprawa i wymiana są niemożliwe lub wymagałyby nadmiernych kosztów dla Gwaranta może on odmówić doprowadzenia towaru do zgodności z udzieloną gwarancją i zaproponować inny sposób załatwienia reklamacji z gwarancji.
8. Wymiany towaru dokonuje punkt sprzedaży, w którym towar został zakupiony (wymiana lub zwrot gotówki) lub autoryzowany punkt serwisowy, jeżeli dysponuje taką możliwością (wymiana). Zwracane urządzenie musi być kompletne, bez uszkodzeń mechanicznych. Niespełnienie tych warunków może spowodować nieuznanie gwarancji.
9. W przypadku braku zgodności towaru z umową sprzedaży, kupującemu z mocy prawa przysługują środki ochrony prawnej ze strony i na koszt sprzedawcy, a gwarancja nie ma wpływu na te środki ochrony prawnej.
10. Niniejsza gwarancja obowiązuje na terytorium Polski.
11. Warunkiem dokonania naprawy lub wymiany urządzenia w ramach gwarancji jest przedstawienie dowodu zakupu oraz użytkowanie towaru zgodnie z informacjami zawartymi w instrukcji obsługi.

UWAGA!

Uszkodzenie lub usunięcie tabliczki znamionowej z urządzenia może spowodować nieuznanie gwarancji.

Cały czas udoskonalamy nasze produkty, dlatego mogą się one nieznacznie różnić od zdjęć przedstawionych na opakowaniu oraz w instrukcji obsługi. Przed przystąpieniem do użytkowania urządzenia przeczytaj instrukcję obsługi.

ART-DOM Sp. z o.o., ul. Zakładowa 90/92, 92-402 Łódź, info@artdom.net.pl. Numer Krajowego Rejestru Sądowego 0000354059.



SAFETY CONDITIONS AND HAZARDS

1. Do not switch the device on if it is damaged, otherwise an electric shock may occur.
2. Protect the product from dirt, moisture and overheating.
3. This product may only be operated by children aged 8 or more, by mentally and/or physically deficient persons, and by persons without knowledge of or experience in operating this appliance provided that they are supervised and/or have been instructed in its safe operation, and as a result have clear understanding of all related risks. Children should not play with the device. Unsupervised children should not carry out maintenance and cleaning of the device.
4. Do not immerse the device in water nor in other liquids.
5. The product should not be used in combination with electrical switches, timers, photocells, etc.
6. Use the product in dry rooms only.
7. Children must not perform cleaning or maintenance without adult supervision.
8. The device can only be connected to a power source with a voltage and frequency matching the specification on the nameplate.
9. The device is suitable for domestic use only. The manufacturer will not be held liable for damages resulting from improper or non-compliant use.
10. Do not pull or carry the device by the power cord. Do not use the cord as a handle.
11. Do not use in damp places such as bathrooms. In the event of liquid entering the device, turn it off and have it inspected by an authorized equipment service centre.

12. Do not use detergents to clean the device.
13. When disconnecting the device from the power source, do not pull the cable. Instead grab the plug by hand and unplug the device.
14. Do not disconnect the device using wet hands.
15. In case of headache or eye pain, turn off the lamp and take a few minutes of a break. Keep an appropriate distance from the direct light source.
16. The product may not operate properly if it stays within the range of an electromagnetic field.
17. The lamp light source is not replaceable. After the light source reaches the end of its service life, the lamp should be replaced with a new one.
18. This product contains a light source with an energy efficiency class of <F>.

INTRODUCTION

Thank you for the trust you have placed in us when you purchased your **MAD DOG** device.

We are convinced that this high quality device will provide you with a lot of joy and satisfaction during its use.

PLEASE CAREFULLY READ AND FOLLOW THE OPERATING MANUAL!

This device is intended for domestic or similar, non-commercial use.


The manufacturer will not be held liable for damages resulting from improper or non-compliant use.

TECHNICAL DATA

MODEL	GML200K
Input [V/A]	5V/1A
Rated power (W)	5W
Colour temperature [K]	3000-6500K
The product has a light source of energy efficiency class	F
Service life [h]	25000h

Brightness adjustment	5 levels
Remote power supply	3 x AAA Battery
Luminous flux [lm]	285
Maximum RF power	-2.27 dBm
Frequency range	2400-2483.5 MHz


DEVICE DESCRIPTION




INITIAL START-UP AND OPERATION

Install the light on the monitor using the holder so that it is stable and connect the power cable that is included in the set.

METHOD OF MOUNTING THE LAMP ON DIFFERENT THICKNESS MONITORS



Insert the battery into the wireless remote and close the housing.



Battery installation

Using the remote control or directly on the lamp, press the button  to start the device. Then adjust the brightness using  and the colour using . On the remote control, you can adjust the brightness and temperature using the slider. You can also enable automatic mode, which will adjust the brightness by itself based on the light level of the room, using the  icon

CZYSZCZENIE I KONSERWACJA

CAUTION! BEFORE CLEANING, TURN OFF THE DEVICE AND DISCONNECT IT FROM THE POWER SUPPLY.

It is recommended to remove the light from the monitor for cleaning. Clean only with a dry cloth.

CAUTION! DO NOT ATTEMPT TO WASH THE DEVICE WITH WATER, DO NOT USE CHEMICALS AS THEY MAY CAUSE DISCOLOURATION..

DECLARATION

ART-DOM Sp. z o.o. hereby declares that the GML200K complies with the relevant requirements of the Union harmonisation legislation: Directive 2014/53/EU and other Union harmonisation legislation. The full text of the EU declaration of conformity is available at the following address: <https://www.artdom.net.pl/deklaracja/GML200K/>

TROUBLESHOOTING

PROBLEM	CAUSE	SOLUTION
The light does not work.	The light is not connected properly.	Make sure that the light is correctly connected
	Faulty cable.	Make sure it was not damaged.
	Remote batteries low	Replace the batteries according to the first start-up and operation
The light is too dark.	Brightness settings are too low.	Check and adjust the brightness settings.
The light does not respond to touch.	Dirt or dust on the touch panel.	Clean the touch panel using a dry cloth.

ECO-FRIENDLY AND ENVIRON-MENTALLY FRIENDLY DISPOSAL

This device is marked, in accordance with Directive 2012/19/EU of the European Parliament and of the Council of 4 July 2012 on waste electrical and electronic equipment (WEEE), with the symbol of a crossed-out waste container:



Do not dispose of the device marked with this symbol together with household waste.

For disposal return the device to your local waste treatment and disposal facility or contact your local authorities.

YOU CAN HELP PROTECT THE ENVIRONMENT!

Proper handling of waste electrical and electronic equipment contributes to avoiding harmful consequences for human health and the environment resulting from the presence of hazardous components and improper storage and processing of such equipment.

WARRANTY CONDITIONS FOR MONITOR LIGHT

1. ART-DOM Sp. z o.o. with its registered office in Łódź (92-402) at ul. Zakładowa 90/92 National Court Register Number 0000354059 (Guarantor) guarantees that the purchased device is free from physical defects. The warranty covers only defects resulting from the causes inherent in the item sold (manufacturing defects).
2. A disclosed defect will be removed at the Guarantor's expense within 14 days from the date of reporting the damage to the authorized service or point of sale.
3. In exceptional cases, e.g. the need to import spare parts from their manufacturer, the repair period may be extended up to 30 days.
4. The warranty period for the user is 24 months from the date of delivery of the goods.
5. The goods are intended for use only in the conditions of an individual household.
6. The present warranty does not cover:
 - a. damage caused by using the device in a manner inconsistent with the user manual,
 - b. mechanical, chemical or thermal damage,
 - c. repairs and modifications made by companies or persons that were not authorized to do so by the manufacturer,
 - d. parts that are easily worn or consumables such as: batteries, bulbs, fuses, filters, knobs, shelves, accessories,
 - e. installation, maintenance, inspection, cleaning, unlocking, removal of contaminants and instruction.
7. The Guarantor will select the mode of defect removal at its own discretion. Removal of a

confirmed defect of the device will take place through warranty repair or replacement of the device. The Guarantor may perform repairs when the Buyer requests replacement or the Guarantor may perform replacements when the Buyer requests repair, if bringing the goods (device) into conformity in accordance with the granted warranty in the manner selected by the buyer proves impossible or would require excessive costs at the part of Guarantor. In particularly justified cases, if both repair and replacement are impossible or would require excessive costs for the Guarantor, the Guarantor may refuse to bring the goods into compliance with the granted warranty and propose another way to settle the warranty claim.

8. The exchange of goods is made at the point of sale at which the goods were purchased (replacement or refund) or an authorized service point, if it offers such service (replacement). The returned device must be complete, without mechanical damage. Failure to comply with these conditions may result in failure to accept the warranty claim.
9. In the event of non-compliance of the goods with the sales contract, the buyer is entitled by law to legal protection measures on the part and at the expense of the seller, and the warranty does not affect these legal protection measures.
10. The warranty is valid in Poland.
11. The condition for the warranty repair or replacement of the device is the presentation of proof of purchase and the use of the goods in accordance with the information contained in the user manual.

CAUTION!

Damage or removal of the rating plate from the device may result in warranty being deemed void.

We are constantly improving our products, so they may differ slightly from the images presented on the packaging and in the user manual. Please read the user manual carefully before operating the device

ART-DOM Sp. z o.o., ul. Zakładowa 90/92, 92-402 Łódź, info@artdom.net.pl. National Court Register number 0000354059.

