


PL/ENG



Mission Air®



E-NECK

***KOMIN GRZEWczy
HEATED SCARF***

***INSTRUKCJA OBSŁUGI
MANUAL***



SPECYFIKACJA

MATERIAŁ: POLAR

ZASILANIE: 5V 2A

MOC: 3,5W

PL

Inne wersje
językowe znajdziesz
na naszej stronie.

OBSŁUGA

- Podłącz komin grzewczy do odpowiedniego zasilania.
- Naciśnij i przytrzymaj przycisk przez ok 3 sekundy, aż zaświeci się czerwona lampka.
- Pojedyncze naciśnięcie przycisku umożliwia przełączanie poziomów ogrzewania między:
- Wysokim ok.55 °C (czerwony), Średnim ok.48 °C (niebieski) i Niskim ok.42°C (zielony).
- Przytrzymaj przycisk przez ok 3 sekundy, aby wyłączyć zasilanie.

CZYSZCZENIE, KONSERWACJA I

DODATKOWE INFORMACJE

Odłącz i wyjmij zasilanie przed przystąpieniem do czyszczenia. Używaj delikatnych detergentów. Zalecane jest delikatne pranie ręczne. Pranie maszynowe jest dozwolone jedynie w niskiej temperaturze, w woreczku ochronnym i na niskich obrotach. Zaleca się naturalne suszenie na powietrzu. Zawsze upewnij się, że ubranie jest całkowicie suche przed jego ponownym użyciem. Nigdy nie podłączaj do zasilania mokrego ubrania. Jeżeli dojdzie do zamoczenia ubrania, niezwłocznie wyłącz funkcję grzania i odłącz zasilanie. Czas ogrzewania zależy od pojemności powerbanku oraz od ustawionego programu pracy. Przykładowo przy pojemności akumulatora 4000mAh czas pracy wynosi ok 4h dla wysokiego, ok 5h dla średniego oraz ok 8h dla niskiego trybu grzania.

WAŻNE INFORMACJE

Nie zakładaj, jeśli komin jest mokry.

Nie zakładaj na gołą skórę.

Nie używaj w przypadku niemowląt, dzieci, osób bezradnych lub osób niewrażliwych na ciepło, takich jakosoby ze słabym krążeniem krwi.

Natychmiast wyłącz zasilanie, jeśli poczujesz dyskomfort.

SPECIFICATION

MATERIAL: POLAR

POWER: 5V 2A

OUTPUT: 3.5W

ENG

You will find other language versions on our website.

CONTROL

- Connect the heater to the appropriate power supply.
- Press and hold the button for about 3 seconds until the red light comes on.
- A single press of the button allows you to switch the heating levels between:
- High approx. 55 °C (red), Medium approx. 48 °C (blue) and Low approx. 42 °C (green).
- Hold the button for about 3 seconds to turn off the power.

CLEANING, MAINTENANCE AND ADDITIONAL INFORMATION

Disconnect and unplug the power before cleaning. Use mild detergents. Gentle hand washing is recommended. Machine washing is only allowed at low temperature, in a protective bag and at low speed. Natural air drying is recommended. Always make sure that the garment is completely dry before reusing it. Never plug in wet clothing. If the clothing gets wet, immediately turn off the heating function and unplug the power. The heating time depends on the capacity of the power bank and the set work program. For example, with a 4000mAh battery capacity, the working time is about 4h for high, about 5h for medium and about 8h for low heating mode.

IMPORTANT INFORMATION

Do not wear if the chimney is wet.

Do not wear on bare skin.

Do not use on infants, children, helpless people or people who are insensitive to heat, such as those with poor circulation.

Turn off the power immediately if you feel any discomfort.



Mission Air®

E-NECK

**KOMIN GRZEWczy
HEATED SCARF**

PRODUCENT/MANUFACTURER:

Mission Air sp. z o.o.

ul. Balonowa 63

64-100 Leszno

NIP 697-237-68-36