

Strona główna » [havit](#) » Instrukcja obsługi hybrydowych słuchawek bezprzewodowych z aktywną redukcją szumów HAVIT H655BT 

Instrukcja obsługi hybrydowych słuchawek bezprzewodowych z aktywną redukcją szumów HAVIT H655BT



 **Instrukcje+**



zawartość


- 1 Produkt i akcesoria:**
- 2 Struktura produkcji**
- 3. Funkcja podstawowa**
- 4 OCIEPLENIE FCC**
- 5 Dokumenty/zasoby**
 - 5.1 Odniesienia**
- 6 powiązanych postów**

Produkt i akcesoria:


- Słuchawki*1



- Kabel audio 3,5 mm*1



- Kabel ładujący typu C*1



- Instrukcja obsługi*1




- Certyfikat jakości*1



Struktura produkcji

1. Przycisk wielofunkcyjny (MFB)
2. Głośność +
3. Tom -
4. Przycisk ANC
5. Port ładowania
6. Wskaźnik LED
7. Mikrofon
8. AUX



Podstawowa funkcja

1. Włączanie/wyłączanie słuchawek Bluetooth
 2. Włączanie: Naciśnij i przytrzymaj przycisk MFB przez 3 sekundy;
 3. Wyłączanie: Naciśnij i przytrzymaj przycisk MFB przez 5 sekund; połączenie Bluetooth
- Postępuj zgodnie z instrukcjami (upewnij się, że telefon ma wbudowaną funkcję Bluetooth)

Funkcja Bluetooth)

1. Włącz słuchawki. Dioda LED zacznie migać naprzemiennie na niebiesko i czerwono, a słuchawki przejdą w tryb parowania.
(Uwaga: Słuchawki mogą automatycznie przejść w tryb parowania po włączeniu, jeśli nie zostaną ponownie połączone. Słuchawki mogą automatycznie połączyć się ponownie z ostatnio sparowanym urządzeniem. Aby to zrobić, wystarczy je włączyć).
2. Aktywuj funkcję Bluetooth i wyszukaj „HAVIT H655BT” korzystając z instrukcji swojego telefonu. Kliknij „HAVIT H655BT”, aby nawiązać połączenie.

Połączenie dwóch urządzeń

Upewnij się, że Bluetooth obu urządzeń jest aktywny.

1. Włącz funkcję parowania Bluetooth w urządzeniu A i wyszukaj „HAVIT H655BT”, aby sparować i połączyć. Po pomyślnym nawiązaniu połączenia rozłącz połączenie Bluetooth. (Nie usuwaj nazwy sparowanego urządzenia).
2. Podłącz słuchawki do urządzenia B, a następnie włącz funkcję parowania Bluetooth w urządzeniu A, aby połączyć słuchawki.
(Uwaga: Połączenie ma wyższy priorytet niż odtwarzanie muzyki. Urządzenie B ma priorytet dla dźwięku, gdy oba urządzenia odtwarzają muzykę lub wideo).

Odtwarzanie muzyki

1. Odtwarzanie/pauza: Naciśnij krótko przycisk MFB
2. POPRZEDNI: Długie naciśnięcie przez 1 s „-”, aby przełączyć na poprzedni utwór
3. NASTĘPNY: Naciśnij i przytrzymaj przez 1 sekundę przycisk „+”, aby przełączyć na następny utwór
4. VOL + : Naciśnij krótko „+”, aby zwiększyć głośność
5. VOL - : Naciśnij krótko „-”, aby zmniejszyć głośność

Przełączanie trybu ANC/dźwięku otoczenia.

Naciśnij krótko przycisk ANC, aby włączyć dźwięk otoczenia, tryb ANC i tryb normalny.

(Uwaga: Po włączeniu słuchawki pozostaną w trybie normalnym. Kolejność przełączania trybów jest następująca: Normalny – ANC WŁ. – Dźwięk otoczenia WŁ.)

Przełączanie trybu gry/trybu muzyki

Kliknij dwukrotnie przycisk ANC, aby przełączyć tryb gry na tryb muzyki.

(Uwaga:

tryb gry: zmniejsza opóźnienie i zapewnia efekt dźwięku przestrzennego. Tryb muzyki: zapewnia zrównoważony dźwięk przy stabilnym połączeniu).

Tryb przewodowy: Podwójny kabel audio 3,5 mm łączący się z urządzeniem audio

1. Plug and play: Connecting the headphone to a music player with the provided dual 3.5mm audio cable, the headphone can be used as wired headphone without starting.
2. In this mode, you can't use any function of the headphone, including play/pause music, volume adjustment, microphone and so on.

Answering incoming calls

Short press the MFB to answer incoming calls.

(Note: Since some mobile phones default to answer calls via their own receiver, please refer to the instructions of your phone and set on your phone.)

End the current call

Short press the MFB to end the current call.

Reject incoming calls

Press the MFB for 1 second when there comes a call.

Last number redial

Double press the MFB to redial the last calling number.

Activate the voice assistant

 Double click the MFB to activate the voice assistant

Restore factory settings

If the earbuds can't pair frequently, please restore the factory settings. You can clear the paired record first and connect your devices again. Long press the MFB for 8 seconds to restore factory settings and the headphone can enter pairing status again, the indicator flashes alternately with blue and red.

To charge the headphone

1. As product is built-in non-removable and
2. rechargeable battery, please use the provided charging cable to charge;
3. Fully charge the product before the first use.;
4. The LED indicator turns red when charging.

After fully charged, the LED indicator will be steady blue.

Notes

a.Please choose the charger that is certified by the regular manufacturer.

b.The battery performance may decrease as repeating charging and using the product. It's a normal phenomenon for all rechargeable batteries.

Specification

Headphone Battery: 700mAh

Play Time: 60H(50% vol)/55H(50% vol
with ANC ON)

Talk Time: 60H (50% Vol.)

Charging Time: About 2H

Speaker Size: $\phi 40\text{mm}$

Speaker Frequency: 20hz~20khz

USB Port: Type-C Input Voltage / Current: 5V/1A

Warnings

1. Please follow the instruction to operate
2. Please charge the headphone with input power below 5V/1A, in order to protect the battery;
3. Please store or use the headphone in a normal temperature environment.
4. Please keep the headphone from heat source, such as radiators, hot air regulators, stoves, or other heat generating instruments. As it is not anti-high temperature.
5. Don't jam the ports of the headphone, such as charger port, LED port and microphone etc..
6. In order to protect your hearing and extend the headphone service life, it is not recommended to adjust the volume to the maximum level for a long time.

FCC WARMING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept

any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.



www.havit.hk

	HAVIT H655BT Hybrid Active Noise Cancelling Wireless Headphones [pdf] User Manual 2AI6I-H655BT, 2AI6IH655BT, h655bt, H655BT, Hybrid Active Noise Cancelling Wireless Headphones, H655BT Hybrid Active Noise Cancelling Wireless Headphones, Active Noise Cancelling Wireless Headphones, Wireless Headphones, Headphones
--	--

References

- [User Manual](#)

[Manuals+](#) | [Prześlij](#) | [Głębokie wyszukiwanie](#) | [Polityka prywatności](#) | [@manuals.plus](#) | [YouTube](#)

Niniejsza strona internetowa jest niezależną publikacją i nie jest powiązana ani wspierana przez żadnego z właścicieli znaków towarowych. Znak słowny i logo „Bluetooth®” są zastrzeżonymi znakami towarowymi należącymi do Bluetooth SIG, Inc. Znak słowny i logo „Wi-Fi®” są zastrzeżonymi znakami towarowymi należącymi do Wi-Fi Alliance. Jakiegokolwiek użycie tych znaków na tej stronie internetowej nie oznacza żadnego powiązania ani wsparcia.

