

EDIFIER®

T5s Powered Subwoofer

— Quick Start Guide —

Model: EDF100100

Manual Edition 1.0, May 2025
IB-200-1000S5-00

For more information, please visit our website:

www.edifier.com



@Edifierglobal @Edifier_Global @Edifier_Global

Edifier International Limited
P.O. Box 6264
General Post Office
Hong Kong

Tel: +852 2522 6889
Fax: +852 2522 1987

www.edifier.com
© 2025 Edifier International Limited. All rights reserved.
Printed in China

NOTICE:
For the need of technical improvement and system upgrade, information contained herein may be subject to change from time to time without prior notice.
Products of EDIFIER will be customized for different applications. Pictures and illustrations shown on this manual may be slightly different from actual product. If any difference is found, the actual product prevails.



EN What's in the box?
FR Contenu de la boîte
ES Contenido de la caja
DE Lieferumfang
IT Contenuto della confezione
PT Conteúdo da caixa
NL Wat zit er in de doos?
NL Zawartość pudełka
CZ Co je v krabici?
DK Kassens indhold
GR Τι υπάρχει στο κουτί?
SV Vad finns i boxen?
BG Какво има в кутията?
RO Ce se află în cutie?



EN Cable connection
FR Connexion par câble
ES Conexión de cable
DE Kabelverbindung
IT Collegamento cavo
PT Conexão via cabo
NL Kabelverbinding
PL Połączenie kablowe
CZ Připojení kabelu
SK Káblové pripojenie
DK Kabeltilslutning
GR Σύνδεση καλωδίου
SV Kabelanslutning
BG Кабелна връзка
RO Conectare cablu



EN Setup
FR Réglage
ES Configuración
DE Einstellungen
IT Configurazione
PT Configuração
NL Instelling
PL Konfiguracja
CZ Nastavení
SK Nastavenie
DK Opsætning
GR Ρύθμιση
SV Inställningar
BG Настройка
RO Configurare

EN Total output power (RMS): 70 W
FR Puissance totale de sortie (RMS) : 70 W
ES Potencia total de salida (RMS): 70 W
DE Gesamt-Ausgangsleistung (RMS): 70 W
IT Potenza di uscita totale (RMS): 70 W
PT Potência de saída total (RMS): 70 W
NL Totale uitgang vermogen (RMS): 70 W
PL Całkowita moc wyjściowa (RMS): 70 W
CZ Celkový výstupní výkon (RMS): 70 W
SK Celkový výstupný výkon (RMS): 70 W
DK Udgangs-effekt i alt (RMS): 70 W
GR Συνολικό ισχύος εξόδου (RMS): 70 W
SV Total uteffekt (RMS): 70 W
BG Обща изходна мощност (RMS): 70 W
RO Putere totală de ieșire (RMS): 70 W

Frequency response: 35 Hz-115 Hz
Réponse en fréquence : 35 Hz-115 Hz
Respuesta de frecuencia: 35 Hz-115 Hz
Frequenzgang: 35 Hz-115 Hz
Risposta in frequenza: 35 Hz-115 Hz
Resposta de frequência: 35 Hz-115 Hz
Frequenzbereich: 35 Hz-115 Hz
Частотный диапазон: 35 Hz-115 Hz
Kmitočtová charakteristika: 35 Hz-115 Hz
Frekvénvá adozva: 35 Hz-115 Hz
Frekvensgang: 35 Hz-115 Hz
Ακούγηση συχνототот: 35 Hz-115 Hz
Frequenzbereich: 35 Hz-115 Hz
Честотен обхват: 35 Hz-115 Hz
Răspuns în frecvență: 35 Hz-115 Hz



The full text of the EU declaration of conformity is available at the following internet address: <https://www.edifier.com/global/ue-do-c>




EN Standby & wake-up
FR Veille et réactivation
ES Espera y activación
DE Standby & Reaktivierung
IT Standby e riattivazione
PT Modo de espera e ativação
NL Stand-by en activeren
PL Tryb gotowości i aktywacja
CZ Pohotovostní režim a aktivace
SK Pohotovostný režim a aktivácia
DK Standby og aktivering
GR Αναμονή και ενεργοποίηση
SV Standby och aktivering
BG Режим на готовост и активиране
RO În așteptare și activare




EN Standby & wake-up
FR Veille et réactivation
ES Espera y activación
DE Standby & Reaktivierung
IT Standby e riattivazione
PT Modo de espera e ativação
NL Stand-by en activeren
PL Tryb gotowości i aktywacja
CZ Pohotovostní režim a aktivace
SK Pohotovostný režim a aktivácia
DK Standby og aktivering
GR Αναμονή και ενεργοποίηση
SV Standby och aktivering
BG Режим на готовост и активиране
RO În așteptare și activare



EN Volume adjustment
FR Réglage du volume
ES Ajuste de volumen
DE Lautstärkenverstellung
IT Regolazione del volume
PT Ajuste de volume
NL Volume aanpassing
PL Regulacja głośności
CZ Úprava hlasitosti
SK Nastavenie hlasitosti
DK Lydstyring
GR Ρύθμιση έντασης
SV Volyminställning
BG Регулиране на звука
RO Reglarea volumului




EN Volume adjustment
FR Réglage du volume
ES Ajuste de volumen
DE Lautstärkenverstellung
IT Regolazione del volume
PT Ajuste de volume
NL Volume aanpassing
PL Regulacja głośności
CZ Úprava hlasitosti
SK Nastavenie hlasitosti
DK Lydstyring
GR Ρύθμιση έντασης
SV Volyminställning
BG Регулиране на звука
RO Reglarea volumului




EN Volume adjustment
FR Réglage du volume
ES Ajuste de volumen
DE Lautstärkenverstellung
IT Regolazione del volume
PT Ajuste de volume
NL Volume aanpassing
PL Regulacja głośności
CZ Úprava hlasitosti
SK Nastavenie hlasitosti
DK Lydstyring
GR Ρύθμιση έντασης
SV Volyminställning
BG Регулиране на звука
RO Reglarea volumului



EN Volume adjustment
FR Réglage du volume
ES Ajuste de volumen
DE Lautstärkenverstellung
IT Regolazione del volume
PT Ajuste de volume
NL Volume aanpassing
PL Regulacja głośności
CZ Úprava hlasitosti
SK Nastavenie hlasitosti
DK Lydstyring
GR Ρύθμιση έντασης
SV Volyminställning
BG Регулиране на звука
RO Reglarea volumului




EN Volume adjustment
FR Réglage du volume
ES Ajuste de volumen
DE Lautstärkenverstellung
IT Regolazione del volume
PT Ajuste de volume
NL Volume aanpassing
PL Regulacja głośności
CZ Úprava hlasitosti
SK Nastavenie hlasitosti
DK Lydstyring
GR Ρύθμιση έντασης
SV Volyminställning
BG Регулиране на звука
RO Reglarea volumului



EN Volume adjustment
FR Réglage du volume
ES Ajuste de volumen
DE Lautstärkenverstellung
IT Regolazione del volume
PT Ajuste de volume
NL Volume aanpassing
PL Regulacja głośności
CZ Úprava hlasitosti
SK Nastavenie hlasitosti
DK Lydstyring
GR Ρύθμιση έντασης
SV Volyminställning
BG Регулиране на звука
RO Reglarea volumului



EN Volume adjustment
FR Réglage du volume
ES Ajuste de volumen
DE Lautstärkenverstellung
IT Regolazione del volume
PT Ajuste de volume
NL Volume aanpassing
PL Regulacja głośności
CZ Úprava hlasitosti
SK Nastavenie hlasitosti
DK Lydstyring
GR Ρύθμιση έντασης
SV Volyminställning
BG Регулиране на звука
RO Reglarea volumului



EN Volume adjustment
FR Réglage du volume
ES Ajuste de volumen
DE Lautstärkenverstellung
IT Regolazione del volume
PT Ajuste de volume
NL Volume aanpassing
PL Regulacja głośności
CZ Úprava hlasitosti
SK Nastavenie hlasitosti
DK Lydstyring
GR Ρύθμιση έντασης
SV Volyminställning
BG Регулиране на звука
RO Reglarea volumului

EN	Wake-up	Standby
Indicator	Green	Red
FR	Reactivation	Veille
Indicator	Vert	Rouge
ES	Activación	Espera
Indicator	Verde	Ros
DE	Reaktivierung	Standby
Anzeige	Grün	Rotes
IT	Riattivazione	Standby
Indicatore	Verde	Rosso
PT	Ativação	Espera
Indicator	Verde	Vermelho
NL	Activeren	Stand-by
Indicatortekst	Groen	Rood
SK	Nastavenie	Trpný stav
Kontrolka	Zelená	Červená
CZ	Alarm	Pohotovostní režim
Kontrolka	Zelená	Červená
SK	Nastavenie	Pohotovostný režim
Indikator	Zelená	Červená
DK	Lydstyring	Standby
Indikator	Grøn	Rød
GR	Ενεργοποίηση	Αναμονή
Edifier logo	Lydstyring	Standby
Indikator	Grøn	Rød
BG	Активиране	Превод на готовост
Indikator	Зелен	Червен
RO	Activare	În așteptare
Indicator lumino	Verde	Rosu

