

Dziękujemy za zakup ekranu projekcyjnego Zenwire. Życzymy miłego użytkowania!

Instrukcja montażu:

1. Wyjmij ekran wraz z elementami montażowymi.
2. Zamocuj uchwyt na lewym lub prawym górnym rogu ekranu, upewnij się, że wysokość na jakiej montujesz ekran jest odpowiednia. Zaczep ekran o zamocowany haczyk.
3. Przymocuj haczyk po drugiej stronie ekranu upewniając się, że ekran jest odpowiednio naciągnięty, tak, aby na ekranie nie było zagięć.
4. Analogicznie przymocuj kolejne haczyki odpowiednio naciągając ekran.

Ostrzeżenia i zalecenia

1. Unikaj zaginania produktu aby ograniczyć ilość zagięć na materiale.
2. Ekran nie powinien być mocowany w warunkach zwiększonej wilgotności powietrza, chroń go przed zamoczeniem. Nie narażaj go na ekstremalnie wysokie i niskie temperatury. Chroń go przed uszkodzeniami mechanicznymi.
3. Nie używaj ekranu niezgodnie z jego przeznaczeniem może to skutkować uszkodzeniem.
4. Producent nie ponosi odpowiedzialności za niestosowanie się do zaleceń użytkownika przez użytkownika.
5. Podczas wyświetlania obrazu na ekranie nie patrz bezpośrednio w obiektyw projektora!
6. Trzymaj produkt oraz materiały opakowaniowe z dala od dzieci i zwierząt.
7. Chroń produkt przed nadmierną ekspozycją słoneczną.

Producent: Zenwire Sp. Z.o.o 60-685 Poznań, Wojciechowskiego 6B/133

Wyprodukowano w PRC.



Przedstawiony symbol umieszczony na produktach lub dołączonej do nich dokumentacji informuje, że niesprawnych urządzeń elektrycznych lub elektronicznych nie można wyrzucać razem z odpadami gospodarczymi. Prawidłowe postępowanie w razie konieczności utylizacji, powtórnego użycia lub odzysku podzespołów polega na przekazaniu urządzenia do wyspecjalizowanego punktu zbiórki, gdzie będzie przyjęte bezpłatnie. W niektórych krajach produkt można oddać lokalnemu dystrybutorowi podczas zakupu innego urządzenia.

Prawidłowa utylizacja urządzenia umożliwia zachowanie cennych zasobów i uniknięcie negatywnego wpływu na zdrowie i środowisko, które może być zagrożone przez nieodpowiednie postępowanie z odpadami. Szczegółowe informacje o najbliższym punkcie zbiórki można uzyskać u władz lokalnych.

Nieprawidłowa utylizacja odpadów zagrożona jest karami przewidzianymi w odpowiednich przepisach lokalnych.

Użytkownicy biznesowi w krajach Unii Europejskiej

W razie konieczności pozbycia się urządzeń elektrycznych lub elektronicznych, prosimy skontaktować się z najbliższym punktem sprzedaży lub z dostawcą, którzy udzielą dodatkowych informacji.

Pozbywanie się odpadów, w krajach poza Unią Europejską

Taki symbol jest ważny tylko w Unii Europejskiej. W razie potrzeby pozbycia się niniejszego produktu prosimy skontaktować się z lokalnymi władzami lub ze sprzedawcą celem uzyskania informacji o prawidłowym sposobie postępowania.



Thank you for purchasing the Zenwire projection screen. We wish you a pleasant experience using it!

Assembly Instructions:

1. Remove the screen along with the mounting components.
2. Attach the bracket to the left or right upper corner of the screen. Make sure the height at which you mount the screen is appropriate. Hang the screen on the mounted hook.
3. Attach the hook on the other side of the screen, ensuring that the screen is properly tensioned so that no creases appear on the surface.
4. Similarly, attach the remaining hooks, tensioning the screen appropriately.

Warnings and Recommendations

1. Avoid bending the product to minimize creases in the material.
2. The screen should not be mounted in conditions of increased humidity; protect it from getting wet. Do not expose it to extremely high or low temperatures. Protect it from mechanical damage.
3. Do not use the screen in a way that is inconsistent with its intended purpose, as this may cause damage.
4. The manufacturer is not responsible for the user's failure to comply with the usage recommendations.
5. While projecting an image onto the screen, do not look directly into the projector lens!
6. Keep the product and packaging materials away from children and animals.
7. Protect the product from excessive exposure to sunlight.

Manufacturer: Zenwire Sp. Z.o.o 60-685 Poznań, Wojciechowskiego 6B/133
Manufactured in PRC.



The symbol shown on products or accompanying documentation indicates that faulty electrical or electronic devices must not be disposed of with household waste. Proper handling for disposal, reuse, or recycling involves taking the device to a specialized collection point where it will be accepted free of charge. In some countries, the product can be returned to the local distributor when purchasing another device. Proper disposal of the device allows for the conservation of valuable resources and prevents negative impacts on health and the environment, which could be endangered by improper waste handling. Detailed information on the nearest collection point can be obtained from local authorities. Improper disposal of waste is subject to penalties provided by relevant local regulations.

Business users in the European Union

If you need to dispose of electrical or electronic devices, please contact your nearest point of sale or supplier for additional information.

Disposal of waste outside the European Union

This symbol is only valid in the European Union. If you need to dispose of this product, please contact local authorities or the seller for information on the correct method of disposal.

