OnePlus Buds Pro 2

User Guide & Safety and Warranty

Never Settle

Version1.0

Product Information

Product Name: OnePlus Buds Pro 2 Product Model: E507A	The package contains the following accessories: OnePlus Buds Pro 2 Charging Case Charging Cable (USB-A to USB-C) Safety and Warranty Information Quick Guide Warranty Card Eartips

Replacing ear tips

Choose the ear tips that fit best for a snug, tight seal which ensures consistent sound quality. Check the seal in accessories for ear tips suitable for your ears.

Pairing and connecting

Open the charging case and keep it close to your earbuds. Ensure that the Bluetooth function is enabled on your device. Select your earbuds from the list of available devices, select OnePlus Buds Pro 2 in the Bluetooth pairing list and follow the prompts to complete the connection. If you have previously connected your earbuds to a device, they will automatically reconnect to your last paired device when you open the charging case and remove the earbuds.

Touch Controls

Touch and hold the earbuds to adjust the volume, switch to the next track, or activate the voice assistant. Refer to the OnePlus Buds Pro 2 Quick Guide for more details.

Play control

Tap the charging case to pause the music, and tap twice to resume it. Tap three times to skip to the next track.

Video Control

Tap the charging case three times to switch the video control between TikTok/Douyin and Kuaishou.

Transparency Mode

Tap the charging case three times to turn the Transparency Mode on or off.

Ear Mode On

Open the charging case, and the earbuds will automatically connect to your last-used device. If you have enabled Ear Mode On, the earbuds will automatically pause when you remove one earbud from your ear. To resume playback, place the earbud back in your ear within 20 seconds.

Charging the Buds

Place the earbuds back in the charging compartment, and they will begin charging automatically. Charging time: 10 minutes for up to 7 hours of playback (Transparency Mode off).
Charging time: 10 minutes for up to 5 hours of playback (Transparency Mode on).
OnePlus Buds Pro 2 support wireless charging.

Battery Information

Battery life may vary by usage and environment. For optimal battery performance, avoid exposing the earbuds and charging case to extreme temperatures (below 0°C or above 35°C). The battery can only be replaced in authorized service centers. Contact one of OnePlus's Authorized Service Providers for assistance.

Operation Enhancement

Keep the charging case and earbuds clean and free of debris. Regularly wipe the charging contacts on the earbuds and the charging case with a dry cloth to ensure optimal performance.

Hearing Protection

Adjust the volume to a safe level. To learn more, visit www.oneplus.com/c/hearingprotection or scan the Hearing Protection QR code in the Quick Guide.

Traffic Safety

Comply with all laws and regulations pertaining to traffic safety when using the earbuds while driving.

Cleaning and Care

Clean the earbuds and charging case with a dry cloth. Do not use chemicals or cleaning agents. Do not immerse the earbuds in water.

Storage and Disposal

Store the earbuds in a cool, dry place. Dispose of the earbuds and charging case in accordance with local laws and regulations.

Ear Adaptation Information

Following ear tips selection, ensure the earbud fits the right contour of the ear canal. Please comply with the relevant regulations of the safety, EMC, and radiation standards of the country or region where the product is used.

Hearing

Prolonged listening at high volume may damage your hearing. Please adjust the volume and limit the amount of time you listen to music. Prolonged exposure to high volume may cause temporary or permanent hearing loss. Consult a doctor if you experience ringing in the ears, hearing loss, or other hearing-related issues. Avoid using earbuds while operating a vehicle or in potentially dangerous environments. Pay attention to your surroundings and exercise caution when using earbuds in public or while in motion.

Medical Devices

Consult your doctor or the manufacturer of your medical device before using the earbuds if you have a medical device such as a pacemaker, hearing aid, or implant. Maintain a minimum distance of 15 cm between the earbuds and any medical device to avoid potential interference.

Electronic Interference

Wireless devices can cause interference in nearby electronic devices. Avoid using the earbuds near medical equipment, aircraft, or other sensitive electronic devices to prevent interference.

Environmental Conditions

Use the earbuds in a dry environment. Avoid exposure to high temperatures or extreme cold. Do not expose the earbuds to water, sweat, or other liquids. Do not immerse the earbuds in water or other liquids. Do not use the earbuds in environments with high humidity or dust.

Physical Impact

Avoid dropping the earbuds or subjecting them to physical impact. Improper handling may damage the internal components and affect performance.

Disassembly and Modification

Do not disassemble, modify, or attempt to repair the earbuds or charging case. Unauthorized modifications may compromise the safety and performance of the product and void the warranty.

Battery Safety

Do not puncture, crush, or expose the battery to fire. Improper handling may cause the battery to leak, overheat, or explode. Do not attempt to remove the battery.