TB/ATS
Crystal(2)

Thank you for purchasing this product.
Please read this manual before using the TWS earphones. Your new earphones always deliver an superior performance and exceptional sound quality.

快速入门指南
Quick Start Guide
Crystal (2) Color Bluetooth Earbuds

Made in the Year 2

ACEFAST

温馨提示
Friendly Reminder
注意事項

● 第次使用耳机时，需先为充电仓充电。请确保耳机上的触摸区、指示灯、充电仓的充电接口保持干燥。
● 初次使用耳机时，请先充电。
● 初次使用耳机时，请先充电。

For the first use, you need to take the earbud out of the charging case, turn off the insulating sticker on the earbud, and the earbud starts automatically pairing with the last paired device.
Please charge the earbud first when the power is low.

●初次使用耳机，需先为充电仓充电。请确保耳机上的触摸区、指示灯、充电仓的充电接口保持干燥。
●初次使用耳机，请先将耳机从充电仓取出，关闭耳机上的绝缘贴，耳机会自动配对上次连接的设备。
●当耳机电量不足时，请先为耳机充电。

Product information / 产品信息 / 商品情報 / 제품 정보

Touch area	触摸区
Charging contacts	充电接口
Mic	麦克风
Charging case	充电仓
LED status display	指示灯
Breathing light	呼吸灯
LED (Charging port)	指示灯（充电口）

Parameter / Product list / 参数 / 产品清单 / 商品一覧 / 매개변수 / 제품 목록

Bluetooth version	Bluetooth 5.3
Bluetooth version	Bluetooth 5.3 (TWS)
Bluetooth version	Bluetooth 5.3 (TWS)
Supported profiles	HFP, HSP, A2DP, AVRCP
Supported profiles	HFP, HSP, A2DP, AVRCP
Earbud specifications	5.3mm + 13mm
Earbud specifications	5.3mm + 13mm
Earbud weight	4.5g
Earbud weight	4.5g
Call time	About 3h (70% volume level)
Call time	About 3h (70% volume level)
Standby time	300h
Standby time	300h
Charging case battery	500mAh, high-density lithium ion battery
Charging case battery	500mAh
Charging case charging time	About 2h
Charging case charging time	About 2h
Earbud charging time	About 1h (fully charged)
Earbud charging time	About 1h (fully charged)
Charging case charging time	About 2h (fully charged)
Charging case charging time	About 2h (fully charged)
Earbud size	45mm*35.5mm*24mm
Earbud size	45mm*35.5mm*24mm
Charging case size	70.5mm*35.5mm*28.5mm
Charging case size	70.5mm*35.5mm*28.5mm
Product list	Product list
Product list	Product list
Product list	Product list
Product list	Product list

Product list

Instructions for use / 使用说明 / 使用説明 / 사용 설명서

Charging

Place the earbuds in the charging case, ensure the contacts on the earbuds and the charging case are in contact, and the charging case will automatically start charging. The charging case has a capacity of 500mAh, and it can provide approximately 3 full charges to the earbuds. The charging case can be charged via a USB-C charging port. It takes about 2 hours to fully charge the charging case, and approximately 1 hour to fully charge the earbuds.

Charging status

The charging case will light up when charging. When the battery is low, it will flash red. When the battery is fully charged, it will turn off the indicator light. The earbuds will turn off the indicator light when fully charged.

Breathing light effect

Charging case	When the charging case is charging, the green and yellow light alternate.
Charging case	When the charging case is low on power, the red light flashes slowly.
Charging case	When the charging case is fully charged, it automatically turns off the indicator light.
Earbuds	When the earbuds are charging, the indicator is on. When fully charged, the indicator turns off.

Charging tips

Keep the earbuds and charging case dry. Do not place the earbuds and charging case in extreme temperatures (below -10°C or above 45°C). Do not use the charging case if it is damaged. Do not charge the earbuds and charging case for more than 24 hours at a time.

Bluetooth Pairing

Take the earbuds out of the charging case, and the earbuds will automatically enter pairing mode. Search for "Crystal (2) Color" on your Bluetooth device and connect to the charging case first, then to each earbud.

Pairing tips

If the earbuds are not paired, place them back in the charging case and try again. If the earbuds are paired but not connected, please check if the Bluetooth function on your device is enabled and try reconnecting. If the earbuds are connected but the sound is abnormal, please check the volume settings on your device and adjust the volume.

Operation mode / 操作模式 / 操作モード / 작동 모드

Touch operation

Touch the touch area of the earbud twice to pause/play music. Touch the touch area of the earbud three times to skip to the next track. Touch the touch area of the earbud four times to skip to the previous track.

Left:

Touch twice: Pause/play music

Touch three times: Next track

Touch four times: Previous track

Right:

Touch twice: Pause/play music

Touch three times: Next track

Touch four times: Previous track

Operation method / 操作方法 / 操作方法 / 작동 방법

Touch operation

Touch the touch area of the earbud for more than 2 seconds, turn on the voice prompt, and automatically enter the pairing mode. Pairing is successful when the voice prompt is heard.

Touch the touch area of the earbud twice to pause/play music.

Touch the touch area of the earbud three times to skip to the next track.

Touch the touch area of the earbud four times to skip to the previous track.

Touch the touch area of the earbud five times to enter the voice assistant.

Touch the touch area of the earbud six times to turn on/off the voice prompt.

Touch the touch area of the earbud seven times to restore factory settings.

Pairing

Pairing is successful when the earbuds are paired for the first time. Once the earbuds are paired, they will automatically pair with the last connected device when they are taken out of the charging case.

Connection

Connecting to a device: If a device has been paired, simply remove the earbuds from the charging case to initiate reconnection.

Disconnection: The earbuds will automatically disconnect when they are placed back into the charging case and will automatically reconnect when they are taken out. If you need to disconnect the earbuds from a specific device, you can do so by turning off the Bluetooth function on your device or manually disconnecting the earbuds.

Touch the touch area of the earbud for more than 2 seconds, turn on the voice prompt, and automatically enter the pairing mode.

Touch the touch area of the earbud twice to pause/play music.

Touch the touch area of the earbud three times to skip to the next track.

Touch the touch area of the earbud four times to skip to the previous track.

Touch the touch area of the earbud five times to enter the voice assistant.

Touch the touch area of the earbud six times to turn on/off the voice prompt.

Touch the touch area of the earbud seven times to restore factory settings.

Operation method / 操作方法 / 操作方法 / 작동 방법

Touch operation

Touch the touch area of the earbud for more than 2 seconds, turn on the voice prompt, and automatically enter the pairing mode.

Touch the touch area of the earbud twice to pause/play music.

Touch the touch area of the earbud three times to skip to the next track.

Touch the touch area of the earbud four times to skip to the previous track.

Touch the touch area of the earbud five times to enter the voice assistant.

Touch the touch area of the earbud six times to turn on/off the voice prompt.

Touch the touch area of the earbud seven times to restore factory settings.

Preamp pairing / 配对方法 / ペアリング方法 / 페어링 방법

Bluetooth pairing for Android phones

Bluetooth pairing for iPhone

Bluetooth pairing for Mac

Bluetooth pairing for Windows

Bluetooth pairing for Windows (Alternative method)

Bluetooth pairing for Windows (Alternative method)

Bluetooth pairing for Windows (Alternative method)