封面封底105g金东太空轻过膜,内页80G铜板不过膜

115mm ✕42mm

首页

排页顺序

1

Xiaomi OpenWear Stereo User Manual
Manuel de l'utilisateur du Xiaomi OpenWear Stereo
Manuale utente Xiaomi OpenWear Stereo
Bedienungsanleitung Xiaomi OpenWear Stereo
Manual de usuario de Xiaomi OpenWear Stereo
Manual do utilizador do Xiaomi OpenWear Stereo
Gebruikershandleiding Xiaomi OpenWear Stereo
Manual do utilizador do Xiaomi OpenWear Stereo
Instrukcja obsługi Xiaomi OpenWear Stereo
Xiaomi OpenWear Stereo Gebruikershandleiding

Xiaomi OpenWear Stereo ユーザーマニュアル
Xiaomi OpenWear Stereo 사용자 설명서
Xiaomi OpenWear Stereo 用戶手冊
Xiaomi OpenWear Stereo 使用说明书
Xiaomi OpenWear Stereo ผู้ใช้งาน
Xiaomi OpenWear Stereo Kullanıcı Kılavuzu
Xiaomi OpenWear Stereo

Product Overview 產品介紹
Touch the sensor to adjust the volume or to hear ambient.
用戶觸摸感應器調節音量，以及聆聽環境。

Package Contents 配件清單

First time using 開始使用
Put the two earbuds into the charging case and close the lid. Charging starts automatically. Open the case and the earbuds will pair automatically. 將兩個耳機放入充電盒，蓋上蓋子。開始充電。開啟充電盒，耳機會自動配對。

Retrieving and Returning the Earbuds 取出及歸還耳機
Open the charging case and take out the earbuds. Put them back in the charging case when you are done. 開啟充電盒，取出耳機。使用完畢後，將耳機放回充電盒。

Wearing 佩戴
Gently tilt the earbud to align it with your ear canal for a secure fit. 輕微傾斜耳機，使其與耳道對齊，以獲得穩固佩戴。

Charging 充電

Turning on 開機 Turning off 關機
Tap and hold the sensor for 2 seconds to turn on the earbuds. Tap and hold the sensor for 3 seconds to turn off the earbuds. 長按感應器 2 秒鐘，開啟耳機。長按感應器 3 秒鐘，關閉耳機。

Connecting
Turn on Bluetooth on your device and select "Xiaomi OpenWear Stereo" from the Bluetooth list to complete pairing. 在裝置上開啟藍牙，從藍牙清單中選擇「Xiaomi OpenWear Stereo」以完成配對。

Wird verbunden
Öffnen Sie Ihre Ladeschale und nehmen Sie die Ohrhörer heraus. Sie werden automatisch miteinander verbunden und mit Ihrem Gerät verbunden, wenn Sie sie aus der Ladeschale nehmen. Wenn Sie sie wieder in die Ladeschale legen, werden sie getrennt.

Connessione
Aprire la custodia di ricarica e rimuovere le cuffiette. Si collegano automaticamente tra loro e si connettono al dispositivo quando le si rimuove dalla custodia di ricarica. Quando le si ripone nuovamente nella custodia di ricarica, si disconnettono.

Conectar
Abra el estuche de carga y saque los auriculares. Se emparejan automáticamente entre sí y se conectan a su dispositivo al sacarlos del estuche. Al volverlos a guardar en el estuche, se desconectan.

Conectar
Abra a caixa de carregamento e retire os auriculares. Eles se emparelham automaticamente entre si e se conectam ao seu dispositivo ao serem retirados da caixa de carregamento. Ao guardá-los de volta na caixa, eles se desconectam.

Verbinden
Open de oplaadhoes en haal de oordopjes eruit. Ze worden automatisch met elkaar gekoppeld en verbinden zich met uw apparaat wanneer u ze uit de oplaadhoes haalt. Wanneer u ze terug in de oplaadhoes plaatst, worden ze ontkoppeld.

Połączenie
Otwórz etui ładujące i wyjmij słuchawki douszne. Łączą się ze sobą automatycznie i łączą się z urządzeniem, gdy wyjmujesz je z etui ładującego. Po włożeniu ich z powrotem do etui ładującego zostaną rozłączone.

Подключение
Откройте зарядный футляр и достаньте наушники. Они автоматически подключатся друг к другу и к вашему устройству при извлечении из зарядного футляра. При возвращении в зарядный футляр они отключатся.

Bağlanma
Şarj kutusunu açın ve kulaklıkları çıkarın. Kulaklıklar birbirlerine ve cihazınıza otomatik olarak eşleşir ve kutudan çıkarılmaları durumunda bağlanır. Şarj kutusuna geri koyduğunuzda bağlantıları kesilir.

Connecting Disconnect
Open the charging case and take out the earbuds. They will automatically pair with each other and connect to your device. Put them back in the charging case and they will disconnect automatically. Hold the sensor for 3 seconds to turn off the earbuds manually.

Automatic Reconnection
Open the charging case and take out the earbuds. They will automatically connect to your device. Put them back in the charging case and they will disconnect automatically.

Restoring Factory Settings
Place your earbuds in the charging case and hold the sensor for 5 seconds. Restore factory settings in the Xiaomi OpenWear app.

Function Overview
Double tap: Play/Pause
Triple tap: Next Track

Double tap: Answer/End call
Triple tap: Reject call

英

2

Connecting with App
Download and install the Xiaomi OpenWear app from the App Store or Google Play Store.
Ensure your earbuds are connected to your device via Bluetooth.
Open the app and follow the on-screen instructions to complete the pairing process.
Please ensure your smartphone's Bluetooth and location services are enabled for a successful connection.

Specifications
Model: OW-S1
Product Type: Ear-open sound without obstruction
Bluetooth Version: 5.4
Bluetooth Profile: HFP, HSP, A2DP, AVRCP
Bluetooth Frequency Range: 2402 MHz–2480 MHz
Bluetooth Transmitter Power: 10.00 dBm
Battery Capacity: Left Earbud: 35 mAh; Right Earbud: 35 mAh; Charging Case: 300 mAh
Battery Type: Lithium-ion polymer battery
Charging Interface: USB-C
Charging Time: Approx. 1.5 hours
Battery Life: Approx. 6 hours (at 50% volume)
Charging Cycles: 500 cycles
Operating Temperature: 0°C–35°C
Storage Temperature: -20°C–45°C
Charging Temperature: 0°C–45°C
Dimensions: Left Earbud: 21.5 mm × 18.5 mm × 18.5 mm; Right Earbud: 21.5 mm × 18.5 mm × 18.5 mm; Charging Case: 58.5 mm × 42.5 mm × 27.5 mm
Weight: Left Earbud: 4.5 g; Right Earbud: 4.5 g; Charging Case: 45 g
Water Resistance Rating: IP54

Note: Due to the complex environments of the Bluetooth signal, in order to ensure the stability of the data transmission, please keep the device within a distance of 10 meters from the connected device, and avoid obstructions such as walls and other electronic interference.

Xiaomi OpenWear Stereo 特別提醒
Xiaomi OpenWear Stereo 特別提醒
Xiaomi OpenWear Stereo 特別提醒
Xiaomi OpenWear Stereo 特別提醒
Xiaomi OpenWear Stereo 特別提醒
Xiaomi OpenWear Stereo 特別提醒
Xiaomi OpenWear Stereo 特別提醒

Important Safety Information
Please read this section carefully before using the product.
Please keep this manual for future reference.
Please adjust the volume to a comfortable level before wearing the earbuds.
Do not use the product while driving, cycling, or operating machinery, as it may impair your attention to your surroundings and increase the risk of accidents.
Do not use the product in environments with high noise levels, such as construction sites or busy streets, to avoid hearing damage.
Do not use the product in environments with high temperatures, such as saunas or hot springs, to avoid damage to the product.
Do not use the product in environments with high humidity, such as bathrooms or swimming pools, to avoid damage to the product.
Do not use the product in environments with high dust levels, such as construction sites or dusty streets, to avoid damage to the product.
Do not use the product in environments with high electromagnetic interference, such as near medical devices or electronic equipment, to avoid interference with other devices.
Do not use the product in environments with high vibration, such as while using power tools or on a moving vehicle, to avoid damage to the product.
Do not use the product in environments with high pressure, such as deep sea or high altitude, to avoid damage to the product.
Do not use the product in environments with high salinity, such as near the sea or in salty air, to avoid damage to the product.
Do not use the product in environments with high pollution, such as near factories or in polluted areas, to avoid damage to the product.
Do not use the product in environments with high humidity, such as bathrooms or swimming pools, to avoid damage to the product.
Do not use the product in environments with high temperatures, such as saunas or hot springs, to avoid damage to the product.
Do not use the product in environments with high dust levels, such as construction sites or dusty streets, to avoid damage to the product.
Do not use the product in environments with high electromagnetic interference, such as near medical devices or electronic equipment, to avoid interference with other devices.
Do not use the product in environments with high vibration, such as while using power tools or on a moving vehicle, to avoid damage to the product.
Do not use the product in environments with high pressure, such as deep sea or high altitude, to avoid damage to the product.
Do not use the product in environments with high salinity, such as near the sea or in salty air, to avoid damage to the product.
Do not use the product in environments with high pollution, such as near factories or in polluted areas, to avoid damage to the product.
Do not use the product in environments with high humidity, such as bathrooms or swimming pools, to avoid damage to the product.
Do not use the product in environments with high temperatures, such as saunas or hot springs, to avoid damage to the product.
Do not use the product in environments with high dust levels, such as construction sites or dusty streets, to avoid damage to the product.
Do not use the product in environments with high electromagnetic interference, such as near medical devices or electronic equipment, to avoid interference with other devices.
Do not use the product in environments with high vibration, such as while using power tools or on a moving vehicle, to avoid damage to the product.
Do not use the product in environments with high pressure, such as deep sea or high altitude, to avoid damage to the product.
Do not use the product in environments with high salinity, such as near the sea or in salty air, to avoid damage to the product.
Do not use the product in environments with high pollution, such as near factories or in polluted areas, to avoid damage to the product.

Warranty Notice
Thank you for purchasing Xiaomi products.
Xiaomi OpenWear Stereo is a product of Beijing Xiaomi Mobile Software Co., Ltd. (hereinafter referred to as "Xiaomi"). Please read the following warranty terms carefully before using the product.
Warranty Period
Xiaomi OpenWear Stereo: 1 year
Accessories: 1 year
Warranty Scope
Xiaomi OpenWear Stereo and its accessories are subject to the warranty terms. If a product or component fails to function properly during the warranty period, Xiaomi will provide free repair, replacement, or refund, at its discretion, if the product is found to be defective in materials or workmanship.
Exclusions
The following cases are not covered by the warranty:
1. Damage caused by improper use, such as dropping, impact, or exposure to liquids.
2. Damage caused by unauthorized disassembly, modification, or repair.
3. Damage caused by third-party accessories or software.
4. Normal wear and tear, such as scratches on the surface.
5. Damage caused by exceeding the product's specifications, such as overcharging or overheating.
6. Damage caused by natural disasters, such as lightning strikes or floods.
7. Damage caused by improper storage, such as long-term exposure to high temperatures or humidity.
8. Damage caused by software updates or third-party apps.
9. Damage caused by the use of non-genuine accessories.
10. Damage caused by exceeding the warranty period.
Contact Us
If you have any questions or need assistance, please contact Xiaomi's official customer service.
Thank you for choosing Xiaomi.

Manufacturer: Beijing Xiaomi Mobile Software Co., Ltd.
Address: Building 6, No. 33 Xi'erqi Middle Road, Haidian District, Beijing, China, 100085