

mackie PROFX10V3+ 10 Channel Analog Mixer



mackie PROFX10V3+ 10-kanałowy mikser analogowy

Instrukcja obsługi

[Strona główna](#) » [Mackie](#) » mackie PROFX10V3+ 10-kanałowy mikser analogowy Instrukcja użytkownika 

zawartość

- 1 mackie PROFX10V3+ 10-kanałowy mikser analogowy
- 2 Informacje o produkcji
- 3 Instrukcje użytkowania produktu
- 4 Ważne instrukcje bezpieczeństwa
- 5 schematów połączeń
- Opisy 6 paneli
- 7 Pierwsze kroki
- 8 Dane techniczne
- 9 GWARANCJA I WSPARCIE
- 10 Dokumenty/zasoby
 - 10.1 Odniesienia





mackie PROFX10V3+ 10-kanałowy mikser analogowy

Informacje o produkcie

Dane techniczne:

- **Model:** ProFXv3+
- **Typ:** Mikser analogowy
- **Funkcje:** Ulepszone efekty, Tryby nagrywania przez USB, Bluetooth

Instrukcje użytkowania produktu

Ważne instrukcje bezpieczeństwa:

1. Przeczytaj instrukcję i zachowaj ją do wykorzystania w przyszłości.
2. Należy stosować się do wszystkich ostrzeżeń i instrukcji.

3. Aby zapobiec uszkodzeniom, należy unikać korzystania z urządzenia w pobliżu wody.
4. Urządzenie należy czyścić wyłącznie suchą szmatką.
5. Należy zapewnić odpowiednią wentylację, zachowując minimalną odległość 5 cm wokół urządzenia.
6. Unikaj blokowania otworów wentylacyjnych, aby zapobiec przegrzaniu.
7. Unikaj umieszczania urządzenia w pobliżu źródeł ciepła lub otwartego ognia.
8. Ze względów bezpieczeństwa nie należy manipulować wtyczką spolaryzowaną lub uziemiającą.

Instalacja i konfiguracja:

1. Zainstaluj mikser zgodnie z instrukcją producenta.
2. Zapewnić odpowiednią wentylację wokół urządzenia.
3. Używaj wyłącznie dodatków/akcesoriów wskazanych przez producenta.

Konserwacja i serwis:

1. Wszelkie prace serwisowe należy powierzać wykwalifikowanemu personelowi.
2. Odłączaj urządzenie od zasilania podczas burzy z piorunami lub przez dłuższy czas, gdy nie jest używane.
3. Serwisowanie jest konieczne, jeśli urządzenie uległo uszkodzeniu lub było narażone na działanie wilgoci.

Wskazówki dotyczące użytkowania:

- Należy używać z kompatybilnym wózkiem, stojakiem lub uchwytem, zgodnie ze specyfikacją producenta.
- Unikaj przeciążania gniazdek ściennych i przedłużaczy, aby zapobiec ryzyku pożaru.

Najczęściej zadawane pytania (FAQ):

1. Co powinienem zrobić, jeśli mikser zostanie wystawiony na działanie wilgoci?

Jeśli mikser wejdzie w kontakt z wilgocią, natychmiast odłącz go od zasilania i nie używaj.

Skontaktuj się z wykwalifikowanym personelem serwisowym w celu przeprowadzenia inspekcji i serwisu.

2. **Czy mogę używać dowolnego wózka lub stojaka z mikserem?**

Nie, zaleca się używanie wyłącznie wózków, stojaków lub wsporników określonych przez producenta, aby zapewnić stabilność i bezpieczeństwo.

3. **Jak czyścić mikser?**

Czyść mikser suchą szmatką. Nie używaj płynnych środków czyszczących ani nie zanurzaj urządzenia w wodzie, aby zapobiec uszkodzeniom.

Ważne instrukcje bezpieczeństwa

1. Przeczytaj te instrukcje.
2. Zachowaj tę instrukcję.
3. Przestrzegaj wszystkich ostrzeżeń.
4. Postępuj zgodnie ze wszystkimi instrukcjami.
5. Nie należy używać tego urządzenia w pobliżu wody.
6. Czyścić wyłącznie suchą szmatką.
7. Nie blokuj żadnych otworów wentylacyjnych. Zainstaluj zgodnie z instrukcjami producenta.
8. Minimum distance (5 cm) around the apparatus for sufficient ventilation. The ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, tablecloths, curtains, etc.
9. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
10. No naked flame sources, such as lighted candles, should be placed on the apparatus.
11. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for the replacement of the obsolete outlet.
12. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
13. Only use attachments/accessories specified by the manufacturer.
14. Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/ apparatus combination to avoid injury from tip-over.
15. Unplug this apparatus during lightning storms or when unused for long periods.

16. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
17. This apparatus shall not be exposed to dripping or splashing, and no object filled with liquids, such as vases or beer glasses, shall be placed on the apparatus.
18. Do not overload wall outlets and extension cords as this can result in a risk of fire or electric shock.

CAUTION

RISK OF ELECTRIC SHOCK! DO NOT OPEN!

CAUTION:

TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED PERSONNEL.

- The lightning flash with the arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure, that may be of significant magnitude to constitute a risk of electric shock to persons.
- The exclamation point within an equilateral triangle is intended to alert the user of the presence of important operating and maintaining (servicing) instructions in the literature accompanying the appliance.

19. This apparatus has been designed with Class-I construction and must be connected to a main socket outlet with a protective earthing connection (the third grounding prong).

-  0. This apparatus has been equipped with a rocker-style AC mains power switch. This switch is located on the rear panel and should remain readily accessible to the user.

21. The MAINS plug or an appliance coupler is used as the disconnect device, so the disconnect device shall remain readily operable.

- Apparaten skall anslutas till jordat uttag.

22. The use of apparatus is in moderate climates.

23. This device should be installed and operated with a minimum distance of 20cm between the radiator & your body.

The product can be sold in all EU countries.

- **Bluetooth transmitter Power:** $\leq 8\text{dBm}$
- **Bluetooth transmitter frequency range:** 2.402 – 2.480 GHz

24. **NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, under part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. CAUTION: Changes or modifications to this device not expressly approved by LOUD Audio, LLC. could void the user's authority to operate the equipment under FCC rules. This device complies with Part 15 of the FCC rules and Industry Canada's license-exempt RSS standard(s). Operation is subjected to the following two conditions:
 1. This device may not cause harmful interference, and
 2. This device must accept any interference received, including interference that may cause undesired operation.

25. This apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the radio interference regulations of the Canadian Department of Communications. CAN ICES-003(B)/NMB-003(B)

26. Exposure to extremely high noise levels may cause permanent hearing loss. Individuals vary considerably in susceptibility to noise-induced hearing loss, but nearly everyone will lose some hearing if exposed to sufficiently intense noise for some time. The U.S. Government's Occupational Safety and Health Administration (OSHA) has specified the permissible noise level exposures shown in the following chart.

According to OSHA, any exposure over these permissible limits could result in some hearing loss. To ensure against potentially dangerous exposure to high sound pressure levels, it is recommended that all persons exposed to equipment capable of producing high sound pressure levels use hearing protectors while the equipment is in operation. Ear plugs or protectors in the ear canals or over the ears must be worn when operating the equipment in order to prevent permanent hearing loss if exposure is more than the limits set forth here:

Duration, per day in hours	Sound Level dBA, Slow Response	Typical Example
8	90	Duo in small club
6	92	
4	95	Subway Train
3	97	
2	100	Very loud classical music
1.5	102	
1	105	Matt screaming at Troy about deadlines
0.5	110	
0.25 or less	115	Loudest parts at a rock concert

WARNING

To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

Correct disposal of this product:

This symbol indicates that this product should not be disposed of with your household waste, according to the WEEE directive (2012/19/EU) and your national law. This product should be handed over to an authorized collection site for recycling waste electrical and electronic equipment (EEE). Improper handling of this type of waste could have a possible negative impact on the environment and human health due to potentially hazardous substances that are generally associated with EEE. At the same time, your cooperation in the correct disposal of this product will contribute to the effective usage of natural resources. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, waste authority, or your household waste disposal service.

Hookup Diagrams

Typical Live Sound System

Typical Recording System



Panels Descriptions

ProFX6v3+ & ProFX10v3+





ProFX12v3+





1. Power Connector & Switch Connect the supplied AC power cord to this jack. The power switch turns the mixer on and off. The Power LED will illuminate when powered.
2. 48V Phantom Power Switch Provides 48V for mics, affecting all XLR jacks simultaneously. The +48V LED illuminates when phantom power is engaged.

3. Combo Inputs Connect a balanced or unbalanced mic, instrument or line-level signal using an XLR or 1/4" connector.
4. XLR Inputs Connect a balanced mic or line-level signal using an XLR connector.
5. Line Inputs Connect a balanced or unbalanced line-level signal using a 1/4" connector.
6. 1/8" Input Connect a 1/8" line-level signal from a smartphone, MP3 player, or other signal source.
7. Line/Hi-Z Switch Engage the switch to play a guitar through channels 1-2 without using a DI Box.
8. Insert Connect a serial effects processor, such as a compressor or gate, using a 1/4" Y cable.
9. Low Cut Switch Cuts bass frequencies below 100 Hz at a slope of 18 dB per octave.
10. Gain Gain adjusts the mic/line input sensitivity.
11. Level Set LED Illuminates green to indicate signal.
12. Compressor Reduces the dynamic range of input signals.
13. Equalization Boost or cut the level at certain frequencies to enhance the sound.
14. FX Switch and Knob Engaging this switch assigns the channel to the FX send. The FX to Main Knob adjusts the FX level of the selected channel from the internal FX processor to the main mix.
15. Pan Assign Switch Engage the switch to fully pan channel 1 to the left and channel 2 to the right.
16. Aux Mon, Mon Send & Master Feed stage monitors via the mon send jacks. Each channel has its level control and the master adjusts the overall output level.
17. Bluetooth On/Off and Pair Switches Press the button to turn the Bluetooth channel on and off. Press and hold to pair with a Bluetooth device. The Bluetooth may disconnect when affected by Electrostatic Discharge [ESD]. Manually reconnect the Bluetooth connection.
18. Aux FX, FX Send & Master Feeds the internal FX or an external processor via the FX send jack. Each channel has its level control and the FX master adjusts the overall level sent out to the internal FX and FX outputs.
19. Pan Adjusts how much of the signal is sent to the left and right outputs.
20. Mute Mutes the channel signal. The button illuminates if the mute switch is engaged.
21. Channel Fader Adjusts the level to the main mix.
22. Assign Switches Determines the destination bus(es) of the signal.
23. PFL Solo Switch Allows you to listen to individual channels singly or in combination with other soloed signals. The rude solo LED flashes when solo switches are engaged.

24. Main Out L/R Connect to the inputs of amplifiers, powered speakers, or a serial effects processor.
25. CR Out L/R Feed the inputs of a control room amplifier, studio monitors or a headphone distribution amplifier.
26. Sub-Outs Feed the inputs of a multitrack deck or secondary power amplifiers in a complex installation.
27. FX Footswitch Connect a footswitch to mute or unmute the internal effects.
28. Phones Connect stereo headphones here.
29. Preset Selector and Display Turn the preset selector to choose an effect. The display shows the number of the currently selected effects preset.
30. Main Meters Used to gauge the soloed input or output levels to ensure that the signals are not clipping.
31. CR/Phones Controls the control room and headphones levels.
32. Break Switch and LED Mutes all channel inputs, but allow the USB inputs to pass out of the main outs.
33. Internal FX Routing and FX Assign Switches Route the output of the effect to the monitors, sub-outs and mains independently. Assign the FX to the selected sub-outs.
34. FX Return Fader Adjusts the level of the stereo output from the internal FX processor being added to the main mix.
35. Blend Knob Provides a balance of the channel inputs (left) and USB 3-4 return (right).
36. To Phones/Control Room Switch Routes a mix of the inputs and USB 3-4 to CR/phones outs. Mutes main mix in CR/phones outs when engaged.
37. Sub Out Faders Controls the levels of the signals sent to the sub-outs.
38. Sub Assign Switches Assign each subgroup to the main out L/R.
39. The Main Mix Adjusts the level of the signal sent to the main outputs.
40. USB I/O A 2×4 interface allowing you to stream audio to and from the mixer via computer.
41. USB 3/4 Switch Engaging this switch mutes the 1/8" input, allowing the USB return to flow through the channel instead.
42. Back Button Press this button to return to the previous screen.
43. Record Press the REC button to toggle between the recording modes.

Getting Started

1. Read and understand the Important Safety Instructions on page 2.
2. Turn down all knobs except the channel EQ and pan knobs, and set all the faders fully down.

3. Set all channel EQ knobs and pan knobs at their centre detent.
4. Disengage all switches.
5. Connect cords from the main outs to powered speakers (or to an amplifier connected to passive speakers).
6. Push the line cord securely into the mixer's connector and plug the other end into a grounded AC outlet. The mixer may accept the appropriate voltage as indicated near the connector.
7. Turn the mixer on.
8. Turn the powered speakers (or amplifiers) on.
9. Plug signal sources into the mixer, such as:
 - Microphones plugged into the mic inputs. (Engage phantom power if needed.)
 - Line-level sources such as keyboards, drum machines, or CD players are plugged into the line-level inputs.
 - Smartphone paired and connected via Bluetooth.
10. Be sure that the volume of the input is the same as it would be during normal use.
11. Engage the channel's L-R assign switch (ProFX12v3+) and turn up that channel's fader to the "U" (unity gain) position.
12. Slowly bring up the main fader to a comfortable listening level.
13. Repeat steps 9 to 11 for the other channels.



Technical Specifications

	ProFX6v3+	ProFX10v3+	ProFX12v3+
Noise Characteristics (150 W Source Impedance Equivalent Input Noise) (20 Hz – 20 kHz)	Mic in to insert send out, max gain: –126 dBu Residual Output Noise: All outputs, master levels and channel levels of f: – 95 dBu All outputs, master levels unity, 1 channel level unity: –80 dBu		
Frequency Response	Mic input to any output (Gain at unity): +0, –1 dB, 20 Hz – 30 kHz		
Distortion (THD+N)	Mic Input to Main Output (22 Hz – 80 kHz): <0.02% @ +4 dBu output		
Attenuation and Crosstalk	Adjacent Inputs @ 1 kHz: –90 dB • Inputs to Outputs @ 1 kHz: –80 dB • Fader Off @ 1 kHz: –75 dB		
	Mute Switch/Break Switch Mute @ 1 kHz: –90 dB		
Maximum Levels	All inputs: +22 dBu • Main Mix XLR: +28 dBu • All other outputs: +22 dBu		
USB	Format: USB 2.0, 1 Stereo Input / 2 Stereo Outputs • A/D/A: 24 bit, 44.1 kHz, 48 kHz, 96kHz, 192kHz		
Operating Temperature	0–40° C // 32–104° F		
AC Universal Supply	Output: 12V = 2A Input: 100VAC–240VAC, 50-60 Hz, 0.8A		100 V AC–240 V AC, 50–60 Hz
 Rozmiar (wys. × szer. × gł.)	2,9 × 7,5 × 8,4 cala Wymiary: 74 × 191 × 213 mm	3,3 × 10,7 × 11,9 cala Wymiary: 84 × 272 × 302 mm	4,0 × 13,0 × 14,8 cala Wymiary: 102 × 330 × 376 mm
Waga	2,6 funta 1,2 kg	4,9 funta 2,2kg	7,9 funta 3,6 kg

Wszystkie specyfikacje mogą ulec zmianie

GWARANCJA I WSPARCIE

Odwiedź WWW.MACKIE.COM aby:

- Zidentyfikuj GWARANCJĘ dostępną na lokalnym rynku. Zachowaj paragon w bezpiecznym miejscu.
- Pobierz pełną wersję INSTRUKCJI OBSŁUGI swojego produktu, gotową do wydruku.
- POBIERZ oprogramowanie, oprogramowanie sprzętowe i sterowniki dla swojego produktu (jeśli dotyczy).
- ZAREJESTRUJ swój produkt.
- SKONTAKTUJ SIĘ z pomocą techniczną.

19820 NORTH CREEK PARKWAY #201 • BOTHELL, WA 98011 • USA Telefon: 425.487.4333 •
Bezpłatny numer: 800.898.3211 • Faks: 425.487.4337 • www.mackie.com .

Numer części 2056497 Rev. C 09/23 ©2023 LOUD Audio, LLC. Wszelkie prawa zastrzeżone.

Niniejszym LOUD Audio, LLC oświadcza, że typ sprzętu radiowego [PROFXV3+] jest zgodny z dyrektywą 2014/53/UE. Pełny tekst Deklaracji zgodności UE i zgodności Bluetooth jest dostępny pod następującym adresem internetowym: <https://mackie.com/en/support/drivers-downloads?folderID=27309> .

Dokumenty / Zasoby

mackie PROFX10V3+ 10-kanałowy mikser analogowy [pdf] Instrukcja użytkownika PROFX10V3 10-kanałowy mikser analogowy, PROFX10V3, 10-kanałowy mikser analogowy, mikser kanałowy analogowy, mikser analogowy

Odniesienia

- [MACIEJ](#)
- [Sterowniki/Pliki do pobrania | MACKIE](#)
- [Instrukcja obsługi](#)

Manuals+ , Polityka prywatności

Ta strona internetowa jest niezależną publikacją i nie jest ani powiązana, ani popierana przez żadnego z właścicieli znaków towarowych. Znak słowny „Bluetooth®” i logo są zarejestrowanymi znakami towarowymi należącymi do Bluetooth SIG, Inc. Znak słowny „Wi-Fi®” i logo są zarejestrowanymi znakami towarowymi należącymi do Wi-Fi Alliance. Jakiegokolwiek użycie tych znaków na tej stronie internetowej nie oznacza żadnego powiązania ani poparcia.

